

6-PRODUCT EXHIBITION QUICK REFERENCE

CATEGORY	AIR PURIFIER M SIZE	WATER IONIZER	HYDROGEN BOTTLE PRO	HYDROGEN BOTTLE GO	AIR HUMIDIFIER	H ₂ GENERATOR FACE & BODY
WHAT IT DOES	Treats indoor air using photocatalytic oxidation; targets susceptible VOCs, mold, odors and biological contamination.	Prepares 4 functional water types: Alkaline, Acidic, Hydrogen and Silver Ion.	Premium portable H ₂ platform: high-concentration Hydrogen Water + hydrogen inhalation + smart functions.	Simple everyday portable bottle for fresh Hydrogen Water.	Adds moisture to indoor air; also supports aromatherapy and ambient lighting.	Creates an ultrafine hydrogen-enriched mist for direct face & body skincare.
CORE TECHNOLOGY	Pre-filter + glass TiO ₂ photocatalytic element + 365 nm UV-A + airflow.	Controlled electrolysis using cathode, anode and 100% natural pressed-cotton membrane.	SPE electrolysis with DuPont™ Nafion™ N117 membrane + platinum-coated titanium electrode.	SPE electrolysis with DuPont™ Nafion™ N117 membrane + platinum-coated titanium electrode.	Ultrasonic / piezoelectric ceramic atomization.	160 kHz ultrasonic atomization + molecular hydrogen.
KEY OUTPUT	Photocatalytic treatment rather than only passive filter capture.	pH 2.5–11.2; Alkaline ORP --125 to ~750 mV; Acidic ORP up to +1000 mV; H ₂ up to 300 ppb; Silver Ion 0.01–20 mg/L.	Up to 9000 ppb H ₂ ; ORP down to --750 mV.	Up to ~1500 ppb H ₂ ; ORP down to --650 mV.	Mist output 35 / 100 / 200 / 300 mL/h.	Up to 500 ppb H ₂ ; ORP down to --300 mV.
CAPACITY / COVERAGE	Up to 20.25 m ² / 218 sq ft.	Main pitcher 3.5 L; inner cup 0.5 L. Standard cycle: ~3 L + 0.5 L separated fractions.	350 mL / 11.8 fl oz.	400 mL.	2.4 L tank; up to 36–38 m ² / 90 m ² .	15 mL reservoir.
MODES / CYCLE	Night / Day / Boost.	Alkaline / Acidic / Hydrogen / Silver Ion.	3-min quick mode; 18-min high-saturation / inhalation mode.	~5-minute H ₂ generation cycle.	Night 35; Low 100; Medium 200; High 300 mL/h. Timer 2 / 4 / 6 h.	~55-second mist cycle.
POWER / CHARGING	7 / 22 / 27 W; standby ~5 W. 110–240 V, 50–60 Hz.	110–230 V, 50–60 Hz; ionization up to 350 W; Silver Ion mode up to 10 W.	≤10 W; 4000 mAh main battery + 300 mAh lid; USB-C + wireless charging up to 5 W.	USB Type-C rechargeable. Battery / charging specs not yet confirmed in current source set.	220 V; 25 W.	≤5 W; 1500 mAh; USB-C; ~1–2 h charging; recommended 5 V / 2 A adapter.
NOISE / SIZE / WEIGHT	29 / 31 / 36 dB(A) at 1 m. 17.7 × 25.75 cm. 1.8 kg.	29 × 14 × 25 cm. Up to 1.4 kg.	65 × 65 × 210 mm. 440 g.	Exact size / weight not confirmed in current source set.	Up to 38 dB. 170 × 170 × 300 mm. 990 g.	15.8 × 3.7 × 3 cm. Exact weight not confirmed.
SMART / EXTRA FUNCTIONS	iOS/Android app; schedule; 180-min auto-off; RGB 9 colors / 5 brightness; self-diagnostics; Wi-Fi 2.4 GHz for firmware updates.	Digital display; pH selection; voice prompts; quick menu; tilt protection; Water Mineralizer included.	Touchscreen; iOS/Android app; ppb/ORP display; self-cleaning; reminders in app; mineralization option for alkaline water; inhalation adapter; 7.8 Hz module, UV sterilization, lid for supplements	Countdown timer; soft LED illumination; anti-slip base; simple one-button use.	Aromatherapy with 100% natural essential oils; constant / flicker / candle light; auto shut-off when water runs out.	Simple slide-to-start operation; blue operation indicator.
MAINTENANCE / CONSUMABLES	Pre-filter replacement every 6 months; long-life glass photocatalytic element; keep inlets/outlet clean.	Cotton membrane up to ~3 months; mineral descaling; cathode cleaning; Silver electrode cleaning; device life up to 12 years.	Self-clean monthly; mineral pouch ~3–6 months; keep charging port dry; do not generate H ₂ while charging.	Use drinking water; rinse regularly; keep charging port dry. Exact service interval not yet confirmed.	3 filters included (1 installed + 2 spare); atomizer >5,000 h. Exact filter-change interval still to confirm.	Monthly clean: 3 g citric acid + 30 mL warm water, 30 min; keep nozzle/USB port clean.
BEST USE	Desk, bedroom, office, hotel room, personal occupied zone.	Home/kitchen: drinking, food prep, Hydrogen Water, beauty/personal care and household routines.	Users wanting high H ₂ concentration, inhalation, app and premium functions.	Users wanting simple, fast daily Hydrogen Water at home/work/gym/travel.	Bedroom, living room, nursery, office; dry indoor environments.	Face, neck and body hydration at home, office or while travelling.
MAIN DIFFERENCE	Active photocatalytic reactor instead of relying mainly on disposable HEPA filtration.	Portable 4-function batch ionizer with no plumbing or permanent installation.	Advanced model: up to 9000 ppb + inhalation + touchscreen/app + mineralization for alkaline water.	Simple model: larger 400 mL everyday bottle with minimal controls.	3-in-1: humidifier + aroma diffuser + ambient light.	Personal skin device: direct H ₂ mist to skin, not room humidification or drinking water.
DO NOT CONFUSE / CLAIM	Not a medical device; not a sterilizer; do not invent virus/ozone/space claims; HEPA and photocatalysis solve different problems.	Ionization ≠ purification. Do not claim disease treatment, body alkalization or universal safety of Silver Ion at all concentrations.	Hydrogen inhalation ≠ oxygen therapy / medical treatment. High ppb does not justify medical claims.	Hydrogen Water ≠ alkaline water. Not a purifier or medical device.	Humidifier ≠ Air Purifier. Do not claim room sterilization or medical respiratory benefits.	Not a room humidifier, hot facial steamer, medical nebulizer or serum atomizer. Do not claim guaranteed anti-aging/medical effects.

AIR PURIFIER — M SIZE

AIR PURIFIER — M SIZE

Product Training Guide

1. PRODUCT AT A GLANCE

The M-size Air Purifier is a compact indoor purifier based on **photocatalytic oxidation**.

Air passes through:

Pre-filter → **Glass photocatalytic element** → **365 nm UV-A activation** → **Photocatalytic oxidation** → **Treated air**

Unlike a conventional purifier built mainly around a disposable HEPA filter, its core technology uses an **activated glass photocatalytic surface** designed to act on susceptible organic and biological airborne contaminants.

Key Facts

- **Coverage:** up to 20.25 m² / 218 sq ft
 - **Technology:** photocatalytic oxidation
 - **UV:** 365 nm UV-A
 - **Core element:** long-life glass photocatalytic element
 - **Modes:** Night / Day / Boost
 - **Noise at 1 m:** 29 / 31 / 36 dB(A)
 - **Power:** 7 / 22 / 27 W
 - **Weight:** 1.8 kg / 3.9 lb
 - **Dimensions:** 17.7 × 25.75 cm
 - **Pre-filter:** replacement approximately every 6 months
 - **Control:** device + iOS / Android reference app
 - **Connectivity:** BLE 4.0; 2.4 GHz Wi-Fi for firmware updates
-

2. ONE-LINE EXPLANATION

A compact air purifier that uses a long-life glass photocatalytic element activated by 365 nm UV-A to treat susceptible organic and biological airborne contaminants.

3. 30-SECOND EXPLANATION

This purifier works differently from a conventional HEPA-based system. Air first passes through a simple pre-filter and then through a glass photocatalytic element activated by 365 nm UV-A light. The activated surface is designed to treat susceptible VOCs, odors and biological contaminants rather than relying only on mechanical filter capture. M Size covers up to 20.25 m² and operates from just 29 dB(A).

4. HOW IT WORKS

Step 1 — Air enters

The fan draws surrounding air into the purifier.

Step 2 — Pre-filter

The pre-filter captures larger dust and helps protect the internal purification chamber.

Step 3 — Photocatalytic element

Air passes through the glass photocatalytic structure containing a TiO₂-based active surface.

Step 4 — UV-A activation

365 nm UV-A activates the photocatalytic surface.

Step 5 — Photocatalytic oxidation

Susceptible organic and biological contaminants reaching the active surface can undergo oxidation.

The treated air then returns to the room.

The key idea

HEPA primarily captures.

Photocatalysis actively treats susceptible contaminants at the catalyst surface.

5. WHY THE GLASS ELEMENT MATTERS

The photocatalytic element is one of the main technological differentiators.

The glass structure is designed to provide:

- a stable carrier for the photocatalytic material;
- a large three-dimensional active surface;
- resistance to long-term UV exposure;
- efficient interaction between airflow, UV light and the catalyst.

The technical discussion also identifies **UV reflection/scattering within the glass structure** and strong TiO₂ retention as potential advantages.

These comparative advantages should be quantified only after the supporting technical documentation is confirmed.

Important

The glass element is described in the reference documentation as a **long-life / lifelong component** rather than a routine consumable.

6. WHAT IT IS DESIGNED TO ADDRESS

Bacteria

Bacterial contamination is an important application area for photocatalytic treatment.

Exact reduction percentages and bacterial species should only be quoted from approved laboratory reports.

Mold / Fungal Spores

Photocatalysis is relevant to airborne mold and fungal biological contamination.

The purifier does **not** replace physical mold removal or moisture control in a building.

VOCs

Photocatalysis can act on susceptible volatile organic compounds.

Examples present in the supporting technology materials include:

- formaldehyde
- acetaldehyde
- acetone
- toluene
- n-heptane

Use exact performance figures only when the relevant test is available.

Odors

Many odors are caused by volatile organic molecules.

The technology is designed to act on suitable odor-producing compounds rather than simply covering the smell with fragrance.

Relevant use cases may include:

- pet odors
- food odors
- smoke-related odors
- ammonia-related odors

Viruses

Virus-related claims require specific supporting evidence.

Do **not** independently quote virus-reduction percentages unless the approved laboratory report is available.

7. WHAT IT DOES NOT DO

The purifier should not be presented as a universal solution for every air-quality problem.

It is **not automatically**:

- a medical device;
- a room sterilizer;
- a replacement for ventilation;
- a humidifier or dehumidifier;
- a substitute for professional mold remediation;
- a high-capacity HEPA particle purifier;
- a system that destroys every chemical or inorganic pollutant;
- guaranteed protection against infection.

The pre-filter handles larger dust, while the core photocatalytic system focuses on susceptible organic and biological contamination.

8. M SIZE — MODES & SPECIFICATIONS

Mode	Power	Noise at 1 m
Night	7 W	29 dB(A)
Day	22 W	31 dB(A)
Boost t	27 W	36 dB(A)

Night Mode

Reduced fan speed, reduced UV LED output and lower indicator brightness. Designed for quieter operation.

Day Mode

Balanced everyday operating mode.

Boost Mode

Maximum fan and UV output.

Additional Specifications

- **Coverage:** up to 20.25 m² / 218 sq ft
 - **Dimensions:** 17.7 × 25.75 cm
 - **Weight:** 1.8 kg / 3.9 lb
 - **Input:** 110–240 V, 50–60 Hz
 - **Standby:** approx. 5 W
 - **Power cord:** approx. 177.8 cm / 70 in
-

9. FILTERS & MAINTENANCE

The purifier is **not completely filter-free**.

It contains:

Pre-filter

Captures larger dust before air reaches the photocatalytic chamber.

Recommended replacement:

Approximately every 6 months

The device/app can monitor the pre-filter service interval.

Glass Photocatalytic Element

The core active purification element.

It is described as a **long-life / lifelong component** and is not intended as a routine consumable like a HEPA cartridge.

Best wording

No routine HEPA replacement. Only a simple pre-filter requires periodic replacement.

Do not say:

“There are no filters.”

or

“The device requires zero maintenance.”

10. SMART FUNCTIONS

The reference M-size platform supports:

- Night / Day / Boost mode selection
- automatic operating schedule
- **180-minute Auto Turn Off** when no schedule is stored
- pre-filter life monitoring
- RGB light control
- device settings through the app
- BLE 4.0
- iOS / Android
- 2.4 GHz Wi-Fi for firmware updates

RGB Ring

Reference configuration:

- **9 colors**
- **5 brightness levels**

RGB lighting is separate from the physical body color of the purifier.

Several housing colors will be available, with additional white-label customization under consideration.

11. SELF-DIAGNOSTICS

The purifier monitors key internal systems.

Red blinking indication

Possible **fan malfunction**.

Violet blinking indication

Possible **UV module malfunction**.

Blue blinking indication

Pre-filter replacement required.

Repeating buzzer / overheating

Purification temporarily stops while the unit cools.

Once temperature returns to the normal range, operation can resume.

12. PLACEMENT & SAFE USE

Use the purifier:

- indoors only;
- vertically;
- on a stable table or elevated surface;
- with air inlet and outlet unobstructed.

Do not:

- place it on the floor;
- use it next to a shower, bathtub or sink;
- expose it to heavy steam or direct water;
- place it next to a heater or stove;
- block the air openings;
- use it with a damaged cable;
- allow children or pets to interfere with the device.

Avoid prolonged direct viewing of the UV LEDs through the upper diffuser.

After cold transport

If the device has been transported or stored below freezing:

wait at least 2 hours at room temperature and make sure there is no condensation before switching it on.

Slight odor after long storage

A slight characteristic odor may appear during the first hours after long periods of inactivity as accumulated compounds on the photocatalytic surface are oxidized.

This is described as normal behavior.

13. PERSONAL BREATHING-ZONE CONCEPT

One of the strongest positioning ideas for the purifier is **personal/local air treatment**.

Because M Size is compact and quiet, it can be positioned close to where a person spends time:

- desk
- bedside area
- office workstation
- reception
- hotel room

An internal working distance of approximately **0.5–1 m** has been discussed.

Until formally validated, treat this distance as a positioning concept rather than a certified performance specification.

The simple idea is:

Bring air purification closer to where the person actually breathes and spends time.

14. HOW IT DIFFERS FROM ALTERNATIVES

vs HEPA

HEPA: mechanically captures particles.

Photocatalysis: actively treats susceptible organic and biological contamination on an activated surface.

Do not say HEPA is ineffective. HEPA is excellent for particle filtration; the technologies solve different problems.

vs Activated Carbon

Activated carbon: adsorbs certain gaseous compounds until the material becomes saturated.

Photocatalysis: is designed to oxidize suitable organic compounds on the active surface.

vs UV-C

UV-C: primarily uses direct germicidal UV irradiation.

This system: uses **365 nm UV-A to activate a photocatalytic surface.**

vs Air Ionization

The purifier does not rely primarily on releasing ions into the room.

Its main treatment process occurs **inside the photocatalytic reactor.**

vs Other Photocatalytic Carriers

Other systems may use:

- polypropylene
- metal mesh
- foam ceramic
- photocatalytically coated filter media

The key differentiator here is the **glass three-dimensional photocatalytic element.**

Potential advantages include UV stability, active surface structure, catalyst retention and optical behavior.

Use comparative superiority claims only when supporting evidence is available.

15. KEY SELLING POINTS

Colleagues should remember these points:

1. **Photocatalytic oxidation technology**
 2. **Long-life glass photocatalytic element**
 3. **365 nm UV-A activation**
 4. **Designed for VOCs, odors and biological contamination**
 5. **Up to 20.25 m² / 218 sq ft**
 6. **Only 29 dB(A) in Night mode at 1 m**
 7. **Only 7–27 W across active modes**
 8. **No routine HEPA replacement**
 9. **Simple pre-filter replaced approximately every 6 months**
 10. **Night / Day / Boost modes**
 11. **App scheduling and filter-life monitoring**
 12. **Compact 1.8 kg design**
 13. **Multiple colors and white-label customization potential**
-

16. FEATURE → BENEFIT

Glass photocatalytic element

Benefit: long-life core purification component with reduced dependence on disposable main filters.

Photocatalytic oxidation

Benefit: treats certain organic gaseous and biological contaminants rather than only capturing particles.

Pre-filter

Benefit: protects the internal photocatalytic chamber from larger dust.

Night Mode — 29 dB(A)

Benefit: suitable for quiet occupied spaces.

7–27 W operation

Benefit: low power requirement for regular indoor use.

Compact size

Benefit: easy to position near the occupied area.

Smart scheduling

Benefit: the purifier can follow the user's daily routine automatically.

Filter-life monitoring

Benefit: makes routine maintenance easier to remember.

17. QUICK FAQ

What makes this different from a normal air purifier?

Its core purification technology is photocatalytic oxidation rather than relying only on a disposable mechanical filter.

Does it use HEPA?

No. It uses a pre-filter followed by a glass photocatalytic element.

Does it have any replaceable filter?

Yes. The pre-filter is recommended for replacement approximately every six months.

What room size does it cover?

Up to **20.25 m² / 218 sq ft.**

Is it noisy?

At 1 m: **29 dB(A) Night, 31 dB(A) Day, 36 dB(A) Boost.**

How much power does it use?

7 W Night, 22 W Day, 27 W Boost.

What UV wavelength does it use?

365 nm UV-A.

Does UV itself sterilize the air?

The UV-A activates the photocatalytic surface. Photocatalytic oxidation is the core treatment mechanism.

Does it remove odors?

It is designed to act on susceptible organic molecules responsible for many odors rather than simply masking them.

Does it remove VOCs?

VOC treatment is an important application of photocatalytic oxidation. Exact performance depends on the compound and test conditions.

Does it work against bacteria and mold?

They are relevant biological target categories. Quote exact performance only from approved test reports.

Does it kill viruses?

Only use virus-specific claims supported by approved laboratory evidence.

Does it create ozone?

The reference documentation describes the system as ozone-free. Formal quantitative claims should be supported by the product-specific emission report.

Can it be controlled by phone?

The reference M-size platform supports iOS / Android app control via BLE 4.0.

18. COMMON OBJECTIONS

“HEPA already works.”

Absolutely. HEPA is excellent for particle filtration. This system targets a different part of the air-quality problem using photocatalytic oxidation to treat suitable organic and biological contaminants at an activated surface.

“Photocatalysis isn't new.”

Correct. The scientific principle is established. The differentiation is in how it is engineered — particularly the glass photocatalytic element, reactor geometry, catalyst, UV wavelength and airflow.

“Why glass?”

It provides a stable three-dimensional carrier designed for long-term UV exposure and substantial active surface inside a compact reactor.

“Why is the purifier so small?”

M Size is documented for up to 20.25 m², while its compact format also makes it easy to position close to the occupied area.

“Does it require expensive filters?”

No routine HEPA replacement is required. The simple pre-filter is the regular consumable and is replaced approximately every six months.

19. CLAIMS TO USE CAREFULLY

Do not independently claim:

- “kills all viruses”
- “kills 99.9% of all bacteria”
- “sterilizes the entire room”
- “prevents infection”
- “medical-grade”
- “medical device”
- “removes every pollutant”

- “removes all allergens”
 - “completely eliminates mold”
 - “no filters”
 - “zero maintenance”
 - “NASA technology”
 - “used on the ISS”
 - “space-certified”
 - exact ozone values without the relevant report
 - superiority percentages versus HEPA, ceramic or other carriers without comparative testing
-

20. CORE NUMBERS TO MEMORIZE

Every colleague should know:

20.25 m² / 218 sq ft

Coverage

365 nm

UV-A

29 / 31 / 36 dB(A)

Night / Day / Boost at 1 meter

7 / 22 / 27 W

Night / Day / Boost

1.8 kg / 3.9 lb

Weight

17.7 × 25.75 cm

Dimensions

~6 months

Pre-filter replacement

3 modes

Night / Day / Boost

9 RGB colors

5 brightness levels

180 min

Default Auto Turn Off without stored schedule

21. FIVE THINGS EVERY COLLEAGUE MUST REMEMBER

1.

The core technology is photocatalytic oxidation.

2.

The core element is a long-life glass photocatalytic structure activated by 365 nm UV-A.

3.

The device has a pre-filter — never call it completely filter-free.

4.

M Size covers up to 20.25 m² / 218 sq ft and operates from 29 dB(A) and 7 W.

5.

Never invent efficacy percentages or make virus, medical, ozone or space claims beyond the approved evidence.

22. FINAL POSITIONING

A compact, low-noise photocatalytic air purifier built around a long-life glass active element and designed to treat susceptible organic and biological airborne contamination with limited routine consumables.

The strongest product story is the combination of:

****Photocatalytic oxidation**

- Glass active element
+ 365 nm UV-A
- Compact design
- Up to 20.25 m² coverage
- Low noise
- Low power
- Limited consumables
- Smart control
- White-label customization potential**

WATER IONIZER

WATER IONIZER

Product Training Guide

1. PRODUCT AT A GLANCE

The Water Ionizer is a **portable countertop functional-water system** based on controlled electrolysis.

The full exhibition version prepares **four different types of water**:

1. **Alkaline Water**
2. **Acidic Water**
3. **Hydrogen Water**
4. **Silver Ion**

Each program changes specific measurable properties of the water and is intended for different applications.

Key Facts

- **4 functional-water programs**
- **Selectable pH:** 2.5–11.2
- **Alkaline ORP:** approximately –125 to –750 mV
- **Acidic ORP:** up to approximately +1000 mV
- **Hydrogen:** up to 300 ppb H₂
- **Silver Ion:** 0.01–20 mg/L Ag⁺
- **Maximum batch:** 3.5 L / 118.3 fl oz
- **Internal cup:** 0.5 L / 16.9 fl oz
- **Dimensions:** 29 × 14 × 25 cm / 11.4 × 5.5 × 9.8 in
- **Weight without water:** up to 1.4 kg / 3.1 lb
- **Power:** 110–230 V, 50–60 Hz
- **Maximum ionization power:** 350 W
- **No plumbing**
- **No drilling**
- **No permanent installation**

- **100% natural pressed-cotton membrane**
 - **Water Mineralizer included**
 - **36-month device warranty**
 - **Rated device service life: up to 12 years**
 - **White exhibition housing**
 - **Extensive white-label customization available**
-

2. ONE-LINE EXPLANATION

A portable countertop ionizer that uses controlled electrolysis to prepare four types of functional water — Alkaline, Acidic, Hydrogen and Silver Ion — without permanent plumbing.

3. 30-SECOND EXPLANATION

This is a portable Water Ionizer that prepares four different types of functional water from suitable mineralized drinking water. Controlled electrolysis can create alkaline and acidic water with selectable pH, while dedicated programs prepare Hydrogen Water up to 300 ppb H₂ and Silver Ion from 0.01 to 20 mg/L. It prepares up to 3.5 liters per cycle and, unlike traditional plumbed ionizers, it requires no drilling, plumbing or permanent installation.

4. THE CORE IDEA

The strongest concept behind the product is:

FOUR WATER TYPES. FOUR DIFFERENT PURPOSES.

The same device can prepare water with different measurable characteristics for:

- everyday drinking
- food preparation
- Hydrogen Water
- beauty and personal-care routines

- fruit and vegetable washing
- household cleaning
- hygiene applications

The user selects the required program instead of using one fixed type of water for every purpose.

5. HOW WATER IONIZATION WORKS

The main technology is **electrolysis**.

A controlled direct electric current passes through mineralized drinking water between two electrodes separated by a membrane.

The electrodes are:

Cathode

Negative / light electrode

The cathode is made of **medical-grade stainless steel**.

The water around the cathode becomes more alkaline.

It develops:

- higher pH
- increased OH^- concentration
- typically negative ORP

Anode

Positive / dark electrode

The anode is made of **titanium with a surface coating containing iridium and ruthenium oxides**, materials from the platinum-group-metal family.

The water around the anode becomes more acidic.

It develops:

- lower pH
- increased H^+ concentration

- positive ORP

The membrane helps keep these two fractions separated during electrolysis.

Simple explanation

Mineralized water + electrical current + electrodes + membrane → two water fractions with different properties.

6. pH & ORP — WHAT COLLEAGUES NEED TO KNOW

pH

pH shows how acidic or alkaline water is.

pH 7 = neutral

Below 7 = acidic

Above 7 = alkaline

ORP

ORP means:

Oxidation-Reduction Potential

It is measured in:

mV — millivolts

Negative ORP indicates reducing conditions.

Positive ORP indicates oxidizing conditions.

Important

pH ≠ ORP

They measure different properties.

Two waters can have similar pH values but different ORP values.

7. ALKALINE WATER

Range

pH 8.0–11.2

Approximate ORP

–125 to –750 mV

Values depend on:

- source-water composition
- mineralization
- temperature
- selected pH
- operating conditions

Everyday Drinking & Kitchen

pH 8.0–9.4

Relevant for:

- everyday drinking
- beverages
- cooking

The reference manual identifies approximately:

pH 8.5–8.7

as its regular-use range.

Higher pH

pH 9.5–11.2

Better positioned for:

- fruit and vegetable soaking
- food preparation
- degreasing
- kitchen tasks
- household applications

Do not present pH 9.5–11.2 as standard everyday drinking water.

Storage

Best used fresh.

Recommended:

within 8–12 hours

Store in:

- a tightly sealed glass container
- a cool, dark place
- away from direct sunlight and UV

Avoid heating above:

40–45°C / 104–113°F

8. ACIDIC WATER

Range

pH 6.0–2.5

ORP

Up to approximately:

+1000 mV

Acidic Water is mainly positioned for:

- beauty
- personal care
- hair care
- hygiene
- household applications

pH 4.5–5.5

Relevant for:

- face toner
- skin refreshing
- hair rinse

pH 3.0–4.5

Relevant for:

- post-shave routines
- skin-care routines
- hair / scalp routines

Around pH 2.5

Relevant for:

- household surfaces
- cleaning
- textiles
- household tools

Storage

Recommended use:

within 3–5 days

Store tightly sealed, cool and protected from light.

Avoid heating above:

40–45°C / 104–113°F

Important

The source manual contains additional internal-use applications for Acidic Water.

These should **not automatically become exhibition recommendations** without market-specific approval.

9. HYDROGEN WATER

The dedicated Hydrogen Water program prepares drinking water enriched with dissolved molecular hydrogen:

H_2

Hydrogen Concentration

Up to 300 ppb H_2

Equivalent to:

up to 0.30 ppm H_2

ORP

Approximately:

-200 mV

pH

The dedicated Hydrogen Water program does **not intentionally change the source-water pH**.

This is an essential distinction:

HYDROGEN WATER $\neq$ ALKALINE WATER

Hydrogen Water is primarily defined by:

dissolved molecular hydrogen concentration

Alkaline Water is primarily defined by:

pH

They are not the same thing.

Best Use

Hydrogen gradually escapes from water.

Therefore:

Generate → Drink Fresh

Recommended:

within approximately 20–30 minutes

If short-term storage is necessary, use a tightly closed glass container.

Do not boil or heat above:

40°C / 104°F

because dissolved hydrogen escapes.

10. SILVER ION

The full exhibition model includes a dedicated **Silver Ion program**.

The program uses a removable silver electrode.

The user selects the desired Ag^+ concentration and the device introduces silver ions electrochemically into the water.

Range

0.01–20 mg/L Ag^+

Maximum Batch

Approximately:

3.5 L / 118.3 fl oz

Preparation Time

Depending on selected concentration:

approximately 1 second to 200 minutes

Important Technical Point

The Silver Ion program does not intentionally change the source-water pH or ORP.

The primary controlled parameter is:

Ag⁺ concentration

If Silver Ion with a different pH is required, the reference instructions describe preparing the ionized water first and then performing the Silver Ion process.

11. SILVER ION — EXHIBITION USE GUIDE

For straightforward international exhibition communication, use the following applications:

0.1–0.2 mg/L

Fruit & vegetable washing

0.2–0.5 mg/L

External skin care

1–5 mg/L

Dishes & surfaces

5–10 mg/L

Footwear & odor control

10–20 mg/L

Sanitary treatment — external use only

The device technically also offers concentrations beginning at:

0.01 mg/L

The source manual contains lower-concentration drinking and hygiene applications, but these should only be communicated where permitted by local regulation.

13. SILVER ELECTRODE

The Silver Ion function uses a separate removable silver electrode.

Important facts:

- it is installed specifically for Silver Ion preparation;
- it has **no surface coating**;
- it should be removed after use;
- it should be wiped clean and dried after use.

Why does it become darker?

Darkening or surface discoloration is a **normal reaction of silver** during operation.

It does not automatically mean that:

- the electrode is damaged;
- Silver Ion production has stopped;
- the electrode coating has worn away.

There is **no coating on the silver electrode**.

Natural reduction of the electrode's silver mass over time is also considered normal.

Warranty

36 months

Normal silver consumption through use is not considered a manufacturing defect.

14. OUTPUT PER CYCLE

Depending on the selected program, the device produces different water volumes.

Standard Alkaline Configuration

Approximately:

3 L Alkaline Water

-

0.5 L Acidic Water

Reverse Configuration

Approximately:

3 L Acidic Water

-

0.5 L Alkaline Water

Hydrogen Water

Approximately:

3.5 L

Silver Ion

Approximately:

3.5 L

The internal separating cup is **not used** for Hydrogen Water or Silver Ion preparation.

15. SOURCE WATER REQUIREMENTS

The Water Ionizer is **not a water purification system**.

It must start with drinking-quality water.

The technical specification lists approximately:

200–850 ppm mineralization

for ionization.

Water Temperature

Technical operating range:

15–45°C / 59–113°F

For particularly stable and predictable electrolysis, the FAQ recommends approximately:

18–40°C / 64–104°F

Why minerals matter

Electrolysis requires electrical conductivity.

Dissolved mineral ions allow electrical current to pass efficiently through the water.

Water with insufficient mineral content may not ionize correctly.

Therefore, untreated use of:

- distilled water
- strongly demineralized water
- reverse-osmosis water without remineralization

is not recommended.

16. WATER MINERALIZER

A **Water Mineralizer** is included with the Water Ionizer.

Its purpose is to remineralize purified or reverse-osmosis water before ionization.

It helps:

- restore mineral ions removed by purification;
- improve conductivity;
- support stable electrolysis;
- support alkaline-water preparation;
- improve the taste of purified water.

Mineral Profile

Potassium ions K^+ : 20–30 mg/L

Magnesium ions Mg^{2+} : 0–15 mg/L

Calcium ions Ca^{2+} : 6–8 mg/L

Dilution

1:1500

For one Water Ionizer batch:

approximately:

2 mL / 0.07 fl oz

Never consume the concentrated Mineralizer undiluted.

Simple Explanation

Reverse osmosis removes minerals. Electrolysis needs conductivity. The Water Mineralizer restores minerals before ionization.

17. NATURAL-COTTON MEMBRANE

The membrane separates the alkaline and acidic electrolysis zones.

It is made from:

100% natural pressed cotton

The reference manual states that it contains no:

- surfactants
- adhesives

- synthetic additives

Service Life

Up to approximately:

3 months

with regular use and correct care.

Care

After use:

- rinse the inner cup with the membrane installed;
- use a gentle stream of water;
- allow it to dry naturally;
- store only when completely dry.

Do not repeatedly remove the membrane during normal use.

Included Supply

The reference package contains:

15 replacement membranes + 1 membrane pre-installed

18. ELECTRODES & SERVICE LIFE

The device contains:

Cathode

Light / negative electrode

Anode

Dark / positive electrode

The anode has a special surface coating that must be protected from aggressive mechanical cleaning.

Warranty on Cathode & Anode

7 years

Anode Service Life

Up to approximately:

15,000 operating hours

when operating requirements are followed.

The exact electrode base materials and exact anode coating composition still require confirmation.

19. TECHNICAL SPECIFICATIONS

Dimensions

29 × 14 × 25 cm
11.4 × 5.5 × 9.8 in

Main Pitcher

3.5 L / 118.3 fl oz

Internal Cup

0.5 L / 16.9 fl oz

Weight Without Water

Up to 1.4 kg / 3.1 lb

Voltage

110–230 V

Frequency

50–60 Hz

Maximum Ionization Power

350 W

Maximum Silver Ion Mode Power

10 W

Power Cord

165 cm ± 10 cm

Operating Temperature

+5°C to +40°C / 41–104°F

Water Temperature

+15°C to +45°C / 59–113°F

Relative Humidity

Up to 80% at +25°C / 77°F

Housing Protection

IP54

Electrical Protection

Class II

pH Parameter Deviation

Up to approximately:

±5%

depending on water composition and mineral content.

20. WARRANTY & DEVICE LIFETIME

Complete Unit

36-month warranty

Cathode & Anode

7-year warranty

Silver Electrode

36-month warranty

Natural loss of silver mass through normal use is excluded from the warranty.

LCD Display

36-month warranty

in the case of qualifying display defects.

Rated Device Service Life

Up to:

12 years

when operating requirements are followed.

Anode Service Life

Up to:

15,000 operating hours

21. BASIC OPERATING WORKFLOW

For Alkaline and Acidic Water:

1. Position the inner cup according to the required pH.
2. Fill the inner cup first.
3. Fill the main pitcher.
4. Close the lid.

5. Connect power.
6. Select the required pH.
7. Press **START/STOP**.
8. Wait for preparation to finish.
9. Separate the two water fractions.
10. Clean and dry the components.

The device remembers the previously selected pH, so the same setting can be repeated more quickly next time.

Hydrogen Water

Remove the inner cup.

Fill the main pitcher and select the Hydrogen Water program.

Silver Ion

Remove the inner cup.

Install the removable silver electrode.

Select the required Ag^+ concentration and begin preparation.

22. FIRST USE

Before the first normal batch:

1. Remove the lid and inner cup.
2. Rinse the pitcher and inner cup.
3. Reinstall the inner cup.
4. Fill the system as instructed.
5. Start an ionization cycle.
6. **Discard the first prepared alkaline and acidic batch.**

The unit is then ready for normal use.

23. DISPLAY & SMART SAFETY FUNCTIONS

The reference platform includes:

- digital display
- pH selection
- preparation progress
- system messages
- voice prompts
- selectable melody
- adjustable volume
- Simple / Full menu
- quick-select preparation programs
- English / Russian reference interface
- tilt protection

For white-label projects, interface language and presentation can be customized.

Tilt Protection

The full model includes a tilt sensor.

If enabled, ionization / Silver Ion preparation stops when the device is positioned unsafely on an uneven surface.

This provides additional electrical safety.

24. pH TESTING

A liquid pH test is included.

To test the water:

1. Pour approximately **5 mL** into a test cup.
2. Add **4–5 drops** of pH reagent.
3. Mix.
4. Compare the resulting color with the scale.

The included tester measures:

pH only

An ORP meter is required for direct ORP measurement and is **not included** in the standard kit.

25. CLEANING & MAINTENANCE

Electrolysis naturally produces mineral deposits.

Regular cleaning is therefore normal maintenance.

Cathode — Light Electrode

After use:

- wipe the cathode clean;
- if white mineral buildup appears, use a cloth dampened with **9% table vinegar**.

Heavier scale can be removed using the approved vinegar / citric-acid cleaning procedure.

Anode — Dark Electrode

The anode has a special coating.

Do **not** clean it with:

- brushes
- abrasive materials
- aggressive mechanical action

These can damage the surface coating.

Silver Electrode

After use:

- remove it;
- wipe it;
- rinse if necessary;
- dry it.

A mild citric-acid or baking-soda solution can be used according to the maintenance instructions if buildup develops.

Important

Do **not**:

- wash the device in a dishwasher;
 - submerge the electronic block;
 - use water hotter than 40°C for cleaning;
 - connect power during descaling.
-

26. WHITE MINERAL SEDIMENT

A white sediment may appear during ionization.

This occurs because natural minerals such as:

- calcium
- magnesium

can change into less-soluble forms under alkaline electrolysis conditions.

The sediment consists of mineral compounds that were already present in the source water.

It is not automatically:

- contamination;
- a chemical additive;
- evidence of device failure.

Regular descaling is normal maintenance, similar to removing scale from a kettle.

27. WHY WATER MAY WARM DURING IONIZATION

A slight temperature change can occur during operation.

Water conductivity depends on:

- mineral concentration
- mineral composition
- temperature

Different source waters create different electrical resistance.

The device may therefore require different electrical current to maintain electrolysis.

A slight increase in temperature is described as normal and does not automatically indicate a fault.

28. WHAT THE DEVICE IS NOT

The Water Ionizer is **not**:

- a water purifier;
- a reverse-osmosis system;
- a contaminant-removal filter;
- a desalination system;
- a substitute for safe drinking water;
- a medical device;
- a continuous-flow plumbed ionizer.

It changes selected physicochemical properties of suitable drinking water.

It does **not** make contaminated or unsafe source water automatically safe.

29. PORTABLE VS CONVENTIONAL PLUMBED IONIZER

Installation

This Water Ionizer

No plumbing, drilling or permanent connection

Conventional Plumbed Ionizer

Commonly requires connection to a water line and installation.

Mobility

This Water Ionizer

Lift, pack and move.

Conventional Plumbed Ionizer

Usually fixed to one location.

Output

This Water Ionizer

Up to 3.5 L per batch

Conventional Plumbed Ionizer

Typically continuous flow.

Water Functions

Full Exhibition Version

- Alkaline
- Acidic
- Hydrogen
- Silver Ion

Conventional Ionizers

Commonly Alkaline and Acidic; additional functions vary.

Hydrogen

This Water Ionizer

Dedicated program:

up to 300 ppb H₂

Conventional Ionizers

Hydrogen functionality and concentration vary by model.

Space & Installation

This Water Ionizer

Compact countertop body without permanent hoses or under-sink installation.

Conventional Systems

May require countertop hoses and/or under-sink components.

30. WHY PORTABILITY MATTERS

Portability is one of the strongest product differentiators.

The device can:

- move between homes;
- move to another kitchen;
- travel to a second residence;
- be relocated without a plumber;
- operate without drilling or modifying the countertop.

For white-label partners, this also simplifies international distribution because the end customer does not require professional installation.

31. WHITE-LABEL CUSTOMIZATION

The exhibition device will be:

Full 4-program version

White housing

For white-label projects, the product can be extensively customized according to the customer's requirements.

Potential customization includes:

- body color
- finish
- logo
- product name
- interface
- language
- packaging
- manual
- inserts
- exterior graphics
- branding

Additional colors can be produced for customized projects.

32. KEY SELLING POINTS

Every colleague should know these points:

1. **Four functional-water programs in one device**
2. **Alkaline + Acidic + Hydrogen + Silver Ion**
3. **Selectable pH 2.5–11.2**
4. **Hydrogen Water up to 300 ppb H₂**
5. **Silver Ion 0.01–20 mg/L Ag⁺**
6. **Up to 3.5 L per cycle**
7. **Portable countertop format**

8. **No plumbing or drilling**
 9. **100% natural pressed-cotton membrane**
 10. **Water Mineralizer included**
 11. **No integrated proprietary high-cost filtration system**
 12. **Up to 12-year rated device service life**
 13. **7-year cathode/anode warranty**
 14. **15,000-hour anode service life**
 15. **White-label customization**
-

33. FEATURE → CUSTOMER BENEFIT

Four Water Programs

Benefit: one device supports drinking, kitchen, beauty and household routines.

pH 2.5–11.2

Benefit: users can select different water properties for different applications.

Hydrogen Water

Benefit: dedicated molecular-hydrogen water without buying a separate basic hydrogen-water device.

Silver Ion

Benefit: adjustable Ag^+ concentration creates additional hygiene and household-use functions.

3.5 L Capacity

Benefit: family-size preparation rather than a single glass or bottle.

Portable Design

Benefit: no permanent kitchen modification.

Natural-Cotton Membrane

Benefit: simple separation technology with a replaceable natural-material membrane.

Water Mineralizer

Benefit: purified / RO water can be remineralized before ionization.

Long Device Lifetime

Benefit: designed as a long-term household appliance rather than a short-life gadget.

34. QUICK FAQ

What does the Water Ionizer do?

It uses controlled electrolysis to prepare water with different pH, ORP, molecular-hydrogen or Silver Ion characteristics.

How many water types can the exhibition model make?

Four: Alkaline, Acidic, Hydrogen and Silver Ion.

What is the pH range?

2.5–11.2

How much water can it prepare?

Up to approximately:

3.5 L / 118.3 fl oz per cycle

Does it need plumbing?

No.

Is it a water filter?

No. Start with suitable drinking water.

Can I use reverse-osmosis water?

Yes, but strongly demineralized RO water should first be remineralized to provide sufficient conductivity.

Why is the Mineralizer included?

It restores minerals and conductivity before electrolysis.

Is Alkaline Water the same as Hydrogen Water?

No.

pH and hydrogen concentration are different parameters.

How much Hydrogen Water does it produce?

Up to:

300 ppb H₂

Does Hydrogen Water change the pH?

The dedicated program keeps pH essentially based on the source water rather than intentionally creating high-pH water.

How quickly should Hydrogen Water be consumed?

Preferably within:

20–30 minutes

What is Silver Ion?

Water enriched with a controlled concentration of Ag⁺ ions using a removable silver electrode.

What Silver Ion concentration can it prepare?

0.01–20 mg/L

Why does the silver electrode turn dark?

This is a normal surface reaction of silver during operation.

Can Silver Ion be used for drinking?

The source manual contains low-concentration drinking applications, but permitted uses vary by market. Do not recommend internal use unless the specific market and concentration have been approved.

How often is the membrane replaced?

Up to approximately:

every 3 months

depending on usage and maintenance.

Why does white sediment appear?

Natural minerals can form insoluble compounds during electrolysis. This is normal.

Can I measure ORP with the included test?

No. The included liquid test measures pH. ORP requires a separate ORP meter.

Can I take the device when moving or travelling?

Yes. It is portable and does not require permanent plumbing. For air transport, airline-specific baggage rules still apply.

35. CROSS-PRODUCT QUESTION: SILVER ION

Can Silver Ion be used in an Air Humidifier?

The operating manual states that Silver Ion produced by the Water Ionizer may be used in the **compatible Air Humidifier** at recommended concentrations.

Can it be used in the Hydrogen Generator for Face & Body?

No.

The manual specifically states that the facial humidifier / hydrogen-water beauty device is **not designed for solutions containing silver ions**.

What about third-party humidifiers, nebulizers or irrigators?

Only if the manufacturer of that specific device explicitly permits water containing additives or metal ions.

36. COMMON OBJECTIONS

“Why not just buy bottled alkaline water?”

This device prepares water fresh and gives you four different functions rather than one fixed bottled product. You can select Alkaline, Acidic, Hydrogen or Silver Ion depending on the intended use.

“Why not install a normal plumbed ionizer?”

This system doesn't require plumbing or permanent installation. You can simply move it if you move house or want to use it in another location.

“I already have reverse osmosis.”

That's compatible with the concept. Reverse osmosis purifies water but also removes many minerals. The included Water Mineralizer restores conductivity so the purified water can then be ionized.

“Why do I need four types of water?”

Because they have different measurable properties and different applications. Drinking water, Hydrogen Water, beauty water and stronger household-use water should not all have the same characteristics.

“Is Hydrogen Water just alkaline water?”

No. Hydrogen concentration and pH are different parameters. The dedicated Hydrogen program focuses on dissolved molecular hydrogen rather than high pH.

“Why does the device need a membrane?”

The membrane keeps the alkaline and acidic electrolysis fractions separated during preparation.

“Why isn't there a built-in water filter?”

Because the device is an ionizer, not a contaminant-removal system. The user starts with suitable drinking water, which keeps the device portable and avoids dependence on a large proprietary filtration system.

37. CLAIMS TO USE CAREFULLY

Do not independently claim:

- “cures disease”
- “treats cancer”
- “treats hypertension”
- “detoxes the body”
- “replaces medication”
- “medical device”
- “alkalizes the human body”
- “makes unsafe water safe”
- “purifies contaminated water”
- “kills every bacteria”
- “Silver Ion cures infections”
- “Silver Ion is safe to drink at every concentration”
- “Acidic Water is safe to drink at every pH”
- “pH 11.2 is everyday drinking water”
- exact health outcomes from Hydrogen Water without approved evidence
- fixed pH / ORP results regardless of source water

Actual water parameters can vary with:

- source-water mineralization
- mineral composition
- temperature
- selected program
- operating conditions

38. DO NOT CONFUSE

Alkaline Water ≠ Hydrogen Water

pH ≠ ORP

Ionization ≠ filtration

Ionization ≠ reverse osmosis

Hydrogen concentration ≠ ORP

Silver Ion ≠ Acidic Water

High-pH household water ≠ everyday drinking water

Mineralization ≠ contamination

Water Mineralizer ≠ drinking mineral concentrate

Portable batch ionizer ≠ plumbed continuous-flow ionizer

39. CORE NUMBERS TO MEMORIZE

Every colleague should know:

4

Water programs

pH 2.5–11.2

Total pH range

pH 8.0–9.4

Alkaline drinking / food range

pH 9.5–11.2

Higher-pH kitchen / household range

–125 to –750 mV

Approximate Alkaline ORP

Up to +1000 mV

Approximate Acidic ORP

300 ppb H₂

Hydrogen Water

~–200 mV

Hydrogen Water ORP

0.01–20 mg/L Ag⁺

Silver Ion

3.5 L / 118.3 fl oz

Maximum batch

0.5 L / 16.9 fl oz

Internal cup

~3 months

Membrane service life

36 months

Complete device warranty

7 years

Cathode / anode warranty

Up to 12 years

Rated device service life

Up to 15,000 hours

Anode service life

40. FIVE THINGS EVERY COLLEAGUE MUST REMEMBER

1.

One portable device prepares four types of functional water: Alkaline, Acidic, Hydrogen and Silver Ion.

2.

The core technology is controlled electrolysis using a cathode, anode and natural-cotton membrane.

3.

It is an ionizer, not a water purifier — always start with suitable drinking water containing enough minerals for electrolysis.

4.

Its strongest commercial differentiator is portability: no plumbing, no drilling and no permanent installation.

5.

Never confuse pH, ORP, Hydrogen concentration and Silver Ion concentration — they are different parameters and create different water functions.

41. FINAL POSITIONING

A portable four-function Water Ionizer that combines Alkaline, Acidic, Hydrogen and Silver Ion programs in one countertop system — without permanent plumbing or installation.

The strongest product story is the combination of:

****Four functional-water programs**

- Controlled electrolysis
- pH 2.5–11.2
- Hydrogen Water up to 300 ppb H₂
- Silver Ion 0.01–20 mg/L
- Up to 3.5 L per cycle
- Natural-cotton membrane
- Water Mineralizer
- Long product lifetime
- No plumbing
- Portable countertop format
- Extensive white-label customization**

HYDROGEN PRO

HYDROGEN WATER BOTTLE PRO

Product Training Guide

1. PRODUCT AT A GLANCE

Hydrogen Water Bottle PRO is a **portable hydrogen-water system** combining:

1. **High-concentration Hydrogen Water**
2. **Portable Hydrogen Inhalation**
3. **Optional mineralization - alkaline-water preparation**

The system uses electrolysis with a **DuPont™ Nafion™ N117 SPE membrane** and a **titanium electrode with platinum coating** to enrich drinking water with dissolved molecular hydrogen.

Key Facts

- **Hydrogen:** up to 9000 ppb H₂
- **ORP:** down to approximately -750 mV
- **Modes:** 3 minutes / 18 minutes
- **Capacity:** 350 mL / 11.8 fl oz
- **Hydrogen inhalation:** dedicated adapter + tube
- **Touchscreen:** cycle time, estimated ppb and ORP
- **Electrode:** titanium with platinum coating
- **Membrane:** DuPont™ Nafion™ N117 SPE
- **Main battery:** 4000 mAh
- **Lid battery:** 300 mAh
- **Charging:** USB-C + wireless charging up to 5 W
- **Bluetooth app**
- **Self-cleaning mode**
- **Mineralization option**
- **Device lifespan:** approximately 8000 operating hours
- **Electrolyzer lifespan:** approximately 8000 hours
- **Body:** Tritan™ + aluminum-alloy housing
- **Weight:** 440 g / 0.97 lb
- **Dimensions:** 65 × 65 × 210 mm / 2.56 × 2.56 × 8.27 in
- **Power consumption:** ≤10 W

2. ONE-LINE EXPLANATION

A premium portable system that produces high-concentration Hydrogen Water up to 9000 ppb and also supports hydrogen inhalation, smart app control and optional mineralization.

3. 30-SECOND EXPLANATION

Hydrogen Water Bottle PRO is our premium hydrogen platform. It uses electrolysis with a DuPont™ Nafion™ N117 membrane and platinum-coated titanium electrode to enrich drinking water with molecular hydrogen. It offers a 3-minute quick drinking mode and an 18-minute high-saturation mode that also supports hydrogen inhalation. Hydrogen concentration can reach up to approximately 9000 ppb, with ORP down to -750 mV. The device also includes a touchscreen, Bluetooth app, self-cleaning, mineralization option for alkaline water, built-in lid for supplements, UV sterilization and both USB-C and wireless charging.

4. WHAT IS HYDROGEN WATER?

Hydrogen Water is drinking water containing dissolved molecular hydrogen: H_2

The important parameter is the amount of dissolved hydrogen in the water.

It is measured in:

- **ppb — parts per billion**
- **ppm — parts per million**

For reference:

1000 ppb = 1 ppm

Therefore:

9000 ppb = 9 ppm

The PRO system is designed to generate significantly higher dissolved-hydrogen concentrations than a basic everyday hydrogen bottle.

Important

Hydrogen Water ≠ Alkaline Water

Hydrogen concentration and pH are different parameters.

A water can contain molecular hydrogen without having a high pH.

5. WHAT ORP MEANS

ORP means:

Oxidation-Reduction Potential

It is measured in millivolts:

mV

Hydrogen-rich water typically develops a negative ORP.

The PRO system is specified at approximately:

down to -750 mV

depending on water quality and operating conditions.

Important

Hydrogen concentration ≠ ORP

A strongly negative ORP can be associated with hydrogen-rich water, but ORP is not a direct measurement of hydrogen concentration.

Hydrogen concentration should be measured separately in ppb / ppm.

6. HOW THE TECHNOLOGY WORKS

The core process is **electrolysis**.

The device uses:

- drinking water
- electrical current
- titanium electrode with platinum coating
- SPE membrane
- controlled electrolysis chamber

During operation, molecular hydrogen is generated and dissolved into the water.

The system uses a:

DuPont™ Nafion™ N117 SPE membrane

and:

titanium electrode with platinum coating

The membrane/electrode architecture helps manage the electrochemical process and supports high-concentration hydrogen generation.

Simple Explanation

Water + electrolysis + SPE membrane + platinum-coated titanium electrode → dissolved molecular hydrogen H₂

7. WHY THE SPE / NAFION SYSTEM MATTERS

The PRO model is not simply a bottle that produces visible gas bubbles.

Its hydrogen-generation system is built around a dedicated electrolysis architecture using:

DuPont™ Nafion™ N117

and:

platinum-coated titanium electrode technology.

For colleagues, the key message is:

The system is engineered to produce and dissolve molecular hydrogen efficiently while separating the electrochemical process through a dedicated membrane.

Avoid claiming that every visible bubble represents dissolved hydrogen concentration.

The relevant parameter is the **measured dissolved H₂ in the finished water**.

8. HYDROGEN GENERATION MODES

The PRO system has two main hydrogen-generation cycles.

3-MINUTE MODE

Positioned as:

Quick Drinking Mode

Best for:

- faster everyday preparation;
 - situations where the user wants Hydrogen Water quickly.
-

18-MINUTE MODE

Positioned as:

Deep Hydrogen Saturation + Inhalation Mode

Used for:

- extended hydrogen generation;
- higher hydrogen saturation;
- hydrogen inhalation;
- mineralization / alkaline option.

The manual states that completed hydrogen-generation cycles can produce approximately:

2000–9000 ppb H₂

and ORP down to:

-750 mV

depending on source-water quality and conditions.

Important

Do not tell customers:

“3 minutes always gives exactly X ppb and 18 minutes always gives exactly 9000 ppb”

unless the final supplier test specifically confirms these values.

9. HYDROGEN WATER PREPARATION

Step 1

Fill the bottle with drinking water up to MAX

Step 2

Close the lid.

Step 3

Press and hold the power control for approximately **3 seconds**.

Step 4

Use the touchscreen to select:

- 3 minutes
- 18 minutes

Step 5

Start electrolysis.

The touchscreen displays:

- cycle timer

- estimated hydrogen concentration in ppb
- ORP in mV

Step 6

When the cycle finishes, the device switches off automatically.

Step 7

Before opening the lid — especially after the 18-minute cycle — press the **pressure-release valve** first.

Then open the lid.

10. WHY THE PRESSURE-RELEASE VALVE MATTERS

Hydrogen generation can create pressure inside the closed container.

The PRO therefore includes a dedicated:

pressure-relief valve

After an extended cycle:

Release pressure first → Then open the lid

This makes opening easier and is an important operating rule.

Do not repeatedly run electrolysis on the same water without replacing it, because pressure may continue to build.

11. HYDROGEN INHALATION

One of the strongest differentiators of PRO is that it combines:

HYDROGEN WATER + HYDROGEN INHALATION

The package includes:

- inhalation adapter
- hydrogen tube

How to Use

1. Remove the normal lid.
2. Fill the device with **350 mL / 11.8 fl oz** of drinking water.
3. Attach the inhalation adapter.
4. Connect the hydrogen tube.
5. Select the **18-minute mode**.
6. Start the cycle and use the inhalation function.

During inhalation, part of the generated hydrogen leaves the device through the tube.

Therefore the hydrogen concentration shown in the water may not reach the maximum possible value.

Important Positioning

Hydrogen inhalation is a **device feature**.

Do not present it as:

- medical treatment;
 - oxygen therapy;
 - treatment for disease;
 - replacement for medical hydrogen equipment.
-

12. WHY PRO IS DIFFERENT FROM A STANDARD HYDROGEN BOTTLE

A basic Hydrogen Water Bottle is primarily designed to:

generate Hydrogen Water → drink it

PRO is a broader hydrogen platform.

It adds:

- much higher potential hydrogen concentration
- 3- and 18-minute programs
- hydrogen inhalation
- touchscreen
- ppb / ORP display
- Bluetooth app
- drinking reminders
- self-cleaning
- battery monitoring
- mineralization / alkaline option
- wireless charging
- additional UV/LED function
- low-frequency module
- premium material construction

This is why PRO should be positioned as the **premium model**, rather than simply a more expensive version of GO.

13. MINERALIZATION / ALKALINE OPTION

PRO also includes a mineralization option.

The package contains: **2 mineral pouches**

The mineral composition is described as:

- shungite
- silicon
- zeolite
- magnesium

The mineral pouches enrich the water with minerals and can increase its pH.

How to Prepare

1. Place the mineral pouch inside the filter cartridge.
2. Fill the bottle with approximately:

250–275 mL / 8.5–9.3 fl oz

3. Place the mineral cartridge inside the bottle.
4. Close the device.

5. Select the hydrogen-generation program.

Recommended cycle:

18 minutes

After preparation:

- remove the mineral cartridge;
- dry it separately;
- do not leave it inside the humid bottle.

Mineral Pouch Service Life

Approximately:

3–6 months

depending on frequency of use.

Important

The manual confirms that mineralization **raises pH**, but does not provide a fixed final alkaline pH.

14. WHAT THE MINERALIZER DOES NOT DO

The mineral pouches enrich the water with minerals.

They are **not a complete water-purification system**.

The manual specifically notes that the minerals do not remove all organic contaminants.

Therefore:

Start with drinking-quality water.

Do not use the mineral pouch as a substitute for proper filtration when source water requires purification.

15. ADDITIONAL UV / LED FUNCTION

The PRO device includes an additional light-based function in the lid.

The manual specifies wavelengths of approximately:

280 / 450 nm

and describes the function as supporting UV sterilization / device operation.

It is controlled separately using the button on the lid.

Important

Until the exact role of each wavelength and corresponding test evidence are finalized, colleagues should **not invent sterilization percentages**.

Do not say:

- “kills 99.99% of bacteria”
- “sterilizes all water”
- “medical UV sterilization”

without the appropriate test.

16. 7.8 Hz LOW-FREQUENCY MODULE

The device also contains an additional:

7.8 Hz low-frequency module

This is listed in the technical specification and is controlled through the lid function.

For exhibition communication, it is safest to describe this simply as:

an additional low-frequency functional module

Do not attach medical, neurological or therapeutic claims to it unless specific evidence and approved wording are provided.

17. TOUCHSCREEN

PRO includes a touchscreen interface.

During hydrogen generation, it can display:

- cycle time
- estimated hydrogen concentration
- ORP
- battery information
- available operating modes

This makes PRO substantially more informative than a simple one-button Hydrogen Water Bottle.

18. BLUETOOTH APP

The PRO system supports Bluetooth connection to a mobile app.

Documented app functions include:

- device pairing
- remote electrolysis control
- timer settings
- drinking reminders
- self-clean / backwash control
- hydrogen ppb monitoring
- ORP monitoring
- battery-level monitoring

Important

The final app name and branding should follow the white-label configuration.

19. BUILT-IN LID COMPARTMENT

The exhibition product specification includes a small integrated lid compartment intended for:

daily vitamins and supplements

This gives the device an additional lifestyle / travel function and supports its premium everyday-use positioning.

The compartment is for **storage**, not for mixing supplements into the electrolysis chamber.

20. TECHNICAL SPECIFICATIONS

Hydrogen Concentration

Up to 9000 ppb H₂

ORP

Down to approximately -750 mV

Cycle Options

3 minutes / 18 minutes

Capacity

350 mL / 11.8 fl oz

Dimensions

65 × 65 × 210 mm
2.56 × 2.56 × 8.27 in

Net Weight

440 g / 0.97 lb

Power

≤10 W

Main Battery

4000 mAh rechargeable lithium battery

Lid Battery

300 mAh

Charging

USB Type-C

Wireless Charging

Up to 5 W

Electrode

Titanium with platinum coating

Membrane

DuPont™ Nafion™ N117 SPE

Body

Tritan™ plastic + aluminum-alloy housing

Device Lifespan

Approximately 8000 operating hours

Electrolyzer Lifespan

Approximately 8000 operating hours

Additional Light Function

280 / 450 nm

Low-Frequency Module

7.8 Hz

21. BATTERY & CHARGING

The device includes a:

4000 mAh main rechargeable battery

and a:

300 mAh lid battery

When battery level falls below approximately:

10% the touchscreen shows a: **Low Battery** warning.

USB-C Charging

Open the rear charging-port cover and use the supplied cable / compatible approved adapter.

Wireless Charging

Place the bottom of the main unit on a compatible wireless charging pad.

Maximum wireless charging power: **5 W**

Important

Do **not** run hydrogen generation while the device is charging.

Do **not** use unsupported fast-charging adapters.

22. FIRST USE

Before using PRO for drinking water for the first time:

1. Remove the membrane protection / moisture cap.
2. Drain the storage liquid.
3. Dispose of the protective cap.
4. Do not reuse it.
5. Fill the device with clean drinking water.
6. Select **Self-Cleaning Mode**.
7. Run the cycle.

8. Drain the water.
9. Repeat the initial cleaning process **3 times**.

Only after this preparation is the unit ready for normal use.

23. SELF-CLEANING & MAINTENANCE

With regular use, the main unit should be cleaned approximately: **at least once per month**

Cleaning Process

1. Fill with clean drinking water.
2. Select **Self-Cleaning Mode**.
3. Run the cleaning cycle.
4. Drain the water.
5. Repeat if necessary.

Exterior Cleaning

Use a slightly damp cloth.

Do not:

- put the device in a dishwasher;
- wash the main unit under running water;
- immerse the base;
- immerse the lid;
- allow moisture into the charging port.

If moisture enters the charging port: **disconnect power and do not use the device until fully dry.**

24. AFTER LONG STORAGE

If the device has not been used for an extended period:

1. Fill it with warm drinking water:

35–45°C / 95–113°F

2. Leave it for approximately:

30 minutes

3. Rinse before normal use.

This helps prepare the internal system and membrane after storage.

25. WATER REQUIREMENTS

Use: **drinking-quality water only**

Do not use:

- carbonated drinks
- juice
- sweet beverages
- tea
- coffee
- other liquids

Maximum water temperature:

45°C / 113°F

Do not expose the device to temperatures below:

0°C / 32°F

Do not leave water standing inside the bottle for longer than:

4 hours

Do not repeatedly run electrolysis on the same water because internal pressure may increase.

26. HOW TO USE HYDROGEN WATER

Hydrogen is a dissolved gas.

After the cycle ends, it gradually escapes from the water.

Therefore:

GENERATE → DRINK FRESH

For best retention of dissolved H₂:

- drink soon after preparation;
- avoid unnecessary opening / storage;
- do not heat or boil the water.

The precise rate of hydrogen loss depends on storage conditions and container handling.

27. WHAT THE PRODUCT IS NOT

PRO is not:

- a water purifier;
- a reverse-osmosis system;
- an oxygen generator;
- a medical inhalation device;
- a medical treatment system;
- a substitute for prescribed therapy;
- a device for carbonated or flavored beverages;
- a system that makes unsafe source water safe.

Always begin with suitable drinking water.

28. PRO VS HYDROGEN WATER BOTTLE GO

This is one of the most important comparisons for colleagues.

PRO

- Hydrogen up to **9000 ppb H₂**
- ORP down to **-750 mV**

- **3- and 18-minute modes**
- **Hydrogen inhalation**
- 350 mL
- Touchscreen
- Estimated ppb / ORP display
- Bluetooth app
- Self-cleaning
- Drinking reminders
- Mineralization / alkaline option
- Wireless charging
- Premium Tritan™ + aluminum-alloy construction

GO

- Hydrogen up to approximately **1500 ppb H₂**
- ORP down to approximately **-650 mV**
- Approximately **5-minute cycle**
- 400 mL
- Simple one-button operation
- No dedicated inhalation positioning
- USB-C charging
- Borosilicate glass body

The simplest distinction is:

GO

Simple everyday Hydrogen Water

PRO

High-concentration Hydrogen Water + inhalation + smart premium functions

29. WHY PRO HAS A SMALLER CAPACITY THAN GO

PRO has a capacity of: **350 mL**

while GO has: **400 mL**

PRO is not designed simply to maximize water volume.

Its architecture prioritizes:

- higher hydrogen concentration
- pressure-controlled generation
- extended 18-minute cycle
- inhalation
- touchscreen electronics
- app integration
- mineralization
- additional functions

Therefore its value proposition is **functionality and concentration**, not maximum bottle volume.

30. WHY HIGHER ppb MATTERS

ppb describes the concentration of dissolved molecular hydrogen.

A higher number means that more dissolved H₂ is present in the water at the point of measurement.

PRO can reach:

up to approximately 9000 ppb

under suitable conditions.

However, colleagues should remember:

- hydrogen concentration varies with source water;
 - operating conditions matter;
 - H₂ begins escaping after preparation;
 - display estimates should not automatically be treated as laboratory measurement;
 - a higher ppb value does not justify making stronger medical claims.
-

31. HYDROGEN WATER VS ALKALINE WATER

These should never be confused.

Hydrogen Water

Main parameter: **dissolved molecular hydrogen — H₂**

Measured in:

ppb / ppm

Alkaline Water

Main parameter: **pH**

PRO's mineralization cartridge can enrich the water with minerals and increase pH.

However, the device's primary technology and positioning remain: **high-concentration molecular Hydrogen Water**

The alkaline/mineralization option is an additional function.

32. KEY SELLING POINTS

Every colleague should know these points:

1. **Up to 9000 ppb H₂**
2. **ORP down to -750 mV**
3. **3-minute quick mode**
4. **18-minute high-saturation / inhalation mode**
5. **Hydrogen Water + hydrogen inhalation in one portable system**
6. **DuPont™ Nafion™ N117 SPE membrane**
7. **Platinum-coated titanium electrode**
8. **350 mL capacity**
9. **Touchscreen with timer, estimated ppb and ORP**
10. **Bluetooth app**
11. **Self-cleaning**

- 12. Drinking reminders
 - 13. Mineralization / alkaline option
 - 14. USB-C + wireless charging
 - 15. 4000 mAh main battery
 - 16. Approximately 8000-hour device / electrolyzer life
 - 17. Premium Tritan™ + aluminum-alloy construction
 - 18. Inhalation adapter and tube included
-

33. FEATURE → CUSTOMER BENEFIT

Up to 9000 ppb H₂

Benefit: high-concentration Hydrogen Water in a portable format.

3-Minute Mode

Benefit: faster everyday preparation.

18-Minute Mode

Benefit: extended generation for higher hydrogen saturation and inhalation use.

Hydrogen Inhalation

Benefit: adds a second hydrogen-use format to the same portable system.

Touchscreen

Benefit: more information and control directly on the device.

ppb / ORP Display

Benefit: allows the user to follow estimated water parameters during operation.

Bluetooth App

Benefit: remote control, reminders and easier monitoring.

Self-Cleaning

Benefit: simplifies routine maintenance.

Mineralization Cartridge

Benefit: gives the user an additional mineralized / higher-pH water option.

Wireless Charging

Benefit: more convenient everyday charging.

4000 mAh Battery

Benefit: portable use without constant connection to power.

34. QUICK FAQ

What does PRO do?

It produces high-concentration Hydrogen Water and also supports portable hydrogen inhalation.

How much hydrogen can it generate?

Up to approximately:

9000 ppb H₂

depending on water quality and operating conditions.

What is the ORP?

Down to approximately:

-750 mV

What modes does it have?

3 minutes and 18 minutes.

Which mode is for everyday drinking?

The 3-minute mode is positioned as the quick drinking mode.

Which mode is used for inhalation?

18-minute mode.

How much water does it hold?

350 mL / 11.8 fl oz

Does it make alkaline water?

It includes a mineralization option using mineral pouches that enrich the water and increase pH. The manual does not specify one fixed final pH.

What is inside the mineral pouch?

The manual lists:

shungite, silicon, zeolite and magnesium.

How long do the mineral pouches last?

Approximately:

3–6 months

depending on usage intensity.

What electrode does it use?

Titanium with a platinum coating.

What membrane does it use?

DuPont™ Nafion™ N117 SPE membrane.

Can I inhale hydrogen from it?

Yes. The PRO package includes a dedicated inhalation adapter and tube and uses the 18-minute mode for this function.

Is hydrogen inhalation a medical treatment?

No medical claim should be made. It is presented as an additional device function.

Why doesn't the water show maximum ppb during inhalation?

Because part of the generated hydrogen is leaving through the inhalation tube instead of remaining dissolved in the water.

Can I control it from my phone?

Yes. The reference platform supports Bluetooth app control.

Does it charge wirelessly?

Yes, up to:

5 W

with a compatible wireless charger.

Can I use fast charging?

No. Follow the approved charging instructions.

Can I generate hydrogen while charging?

No.

Can I put juice or tea in it?

No. Use drinking water only.

Can I wash it under running water?

Do not wash or immerse the main electronic unit or lid under running water.

35. COMMON OBJECTIONS

“Why do I need PRO instead of a normal hydrogen bottle?”

PRO is designed for customers who want more than basic Hydrogen Water. It combines high-concentration generation up to 9000 ppb, hydrogen inhalation, two generation modes, touchscreen control, Bluetooth app, self-cleaning, mineralization and wireless charging in one system.

“Why is the cycle 18 minutes?”

The longer mode is designed for extended hydrogen generation and is also the mode used for the inhalation function.

“Is more ppb automatically better?”

ppb tells you how much dissolved molecular hydrogen is present. PRO is designed for high concentrations, but concentration is only one parameter and does not justify making medical promises.

“Is this just alkaline water?”

No. Hydrogen Water is defined by dissolved H₂. The mineralization cartridge provides a separate option that can increase the water's mineral content and pH.

“Can I use the inhalation instead of drinking the water?”

They are two different available use formats. The device supports both, but neither should be positioned as medical treatment.

“Why does the device need a pressure valve?”

Extended hydrogen generation can increase internal pressure, so the valve allows pressure to be released before the lid is opened.

“Why use a Nafion membrane?”

It is part of the dedicated SPE electrolysis architecture used to manage the hydrogen-generation process together with the platinum-coated titanium electrode.

36. CLAIMS TO USE CAREFULLY

Do not independently claim:

- “cures disease”
- “treats cancer”
- “treats hypertension”
- “prevents disease”
- “detoxes the body”
- “replaces medication”

- “medical device”
- “medical inhalation therapy”
- “oxygen therapy”
- “anti-aging treatment”
- “guaranteed recovery after exercise”
- “9000 ppb is guaranteed with every water source”
- “18 minutes always produces exactly 9000 ppb”
- “kills all bacteria with UV”
- “sterilizes 100% of the water”
- therapeutic effects from the 7.8 Hz module
- a fixed alkaline pH from the mineral cartridge unless measured

Use the product's **measurable technology and functionality** rather than unsupported medical promises.

37. DO NOT CONFUSE

Hydrogen Water ≠ Alkaline Water

Hydrogen concentration ≠ ORP

ppb ≠ pH

Hydrogen inhalation ≠ oxygen inhalation

Hydrogen inhalation ≠ medical therapy

Mineralization ≠ filtration

Mineralization ≠ purification

UV/LED supporting function ≠ guaranteed sterilization

Display estimate ≠ independent laboratory measurement

3-minute mode ≠ guaranteed fixed ppb

18-minute mode ≠ guaranteed 9000 ppb in every condition

38. CORE NUMBERS

Up to 9000 ppb H₂

Hydrogen concentration

Down to -750 mV

ORP

3 minutes

Quick drinking mode

18 minutes

Extended saturation + inhalation mode

350 mL / 11.8 fl oz

Capacity

65 × 65 × 210 mm

Dimensions

440 g / 0.97 lb

Net weight

≤10 W

Power

4000 mAh

Main battery

300 mAh

Lid battery

5 W

Maximum wireless charging

Approx. 8000 hours

Device lifespan

Approx. 8000 hours

Electrolyzer lifespan

3–6 months

Mineral pouch service life

45°C / 113°F

Maximum water temperature

39. FIVE THINGS EVERY COLLEAGUE MUST REMEMBER

1.

PRO is the premium model: high-concentration Hydrogen Water up to 9000 ppb plus hydrogen inhalation.

2.

It uses a DuPont™ Nafion™ N117 SPE membrane and a platinum-coated titanium electrode.

3.

There are two main cycles: 3 minutes for quick drinking and 18 minutes for extended generation / inhalation.

4.

It also offers touchscreen control, Bluetooth app, self-cleaning, mineralization and wireless charging.

5.

Never turn high ppb or inhalation functionality into medical claims. Performance varies with source water and operating conditions.

40. FINAL POSITIONING

A premium portable hydrogen platform combining high-concentration Hydrogen Water, hydrogen inhalation and smart everyday functions in one system.

The strongest product story is:

**Up to 9000 ppb H₂

- ORP down to -750 mV
+ 3- and 18-minute modes
- Hydrogen inhalation
- Nafion™ SPE technology
- Platinum-coated titanium electrode
- Touchscreen
- Bluetooth app
- Self-cleaning
- Mineralization / alkaline option
- USB-C + wireless charging
- Premium portable design**

HYDROGEN GO

HYDROGEN WATER BOTTLE GO

1. PRODUCT AT A GLANCE

Hydrogen Water Bottle GO is a **portable everyday hydrogen-water bottle** designed to make molecular Hydrogen Water simple and convenient.

The user:

fills the bottle → presses the button → waits approximately 5 minutes → drinks fresh Hydrogen Water.

GO is designed for people who want a straightforward Hydrogen Water routine without advanced settings, inhalation or complex controls.

Key Facts

- **Hydrogen concentration:** up to approximately 1500 ppb H₂
 - **ORP:** down to approximately -650 mV
 - **Cycle:** approximately 5 minutes
 - **Capacity:** 400 mL
 - **Body:** borosilicate glass
 - **Portable rechargeable design**
 - **USB Type-C charging**
 - **Simple one-button operation**
 - **Built-in countdown timer**
 - **Soft LED illumination**
 - **Visible hydrogen bubbles**
 - **Anti-slip base**
 - Designed primarily for **daily Hydrogen Water preparation**
-

2. ONE-LINE EXPLANATION

A simple portable bottle that prepares fresh molecular Hydrogen Water in approximately five minutes for everyday use at home, work, the gym or while travelling.

3. 30-SECOND EXPLANATION

Hydrogen Water Bottle GO is our simple everyday model. Fill it with drinking water, press the button and in approximately five minutes it generates fresh Hydrogen Water with concentrations up to around 1500 ppb H_2 and ORP down to approximately -650 mV. It has a 400 mL borosilicate-glass bottle, rechargeable USB-C design, countdown timer and soft LED illumination. GO is designed for customers who want Hydrogen Water without complicated settings or extra functions.

4. WHAT IS HYDROGEN WATER?

Hydrogen Water is ordinary drinking water containing dissolved molecular hydrogen:

H_2

The important parameter is the amount of dissolved H_2 in the water.

Hydrogen concentration is normally measured in:

- **ppb — parts per billion**
- **ppm — parts per million**

For reference:

1000 ppb = 1 ppm

Therefore:

1500 ppb = 1.5 ppm

Important

Hydrogen Water should not automatically be confused with alkaline water.

Hydrogen Water = dissolved H_2

Alkaline Water = higher pH

These are different water characteristics.

5. WHAT ORP MEANS

ORP stands for:

Oxidation-Reduction Potential

It is measured in: **mV — millivolts**

Hydrogen-rich water commonly develops a negative ORP.

GO can reach approximately:

down to -650 mV depending on water and operating conditions.

Important

ORP ≠ hydrogen concentration

ORP gives information about the water's redox conditions.

Hydrogen concentration is measured separately in:

ppb / ppm

6. HOW GO WORKS

The bottle uses electrolysis to generate molecular hydrogen.

In simple terms:

Drinking water → electrolysis → molecular hydrogen H_2 → Hydrogen Water

The generated hydrogen becomes dissolved in the water during the cycle.

The bottle's transparent borosilicate-glass body also allows the user to see the bubble-generation process during operation.

7. SIMPLE 3-STEP USE

One of the strongest GO selling points is simplicity.

STEP 1

Fill

Add suitable drinking water.

STEP 2

Press

Start the hydrogen-generation cycle.

STEP 3

Drink

After approximately five minutes, drink the freshly prepared Hydrogen Water.

There are no complex mode selections required for normal everyday use.

8. HYDROGEN GENERATION

The standard GO cycle lasts approximately:

5 minutes

The device is designed to produce Hydrogen Water up to approximately:

1500 ppb H₂

with ORP down to approximately:

-650 mV

Actual values may vary depending on:

- source water;
- water temperature;
- mineral composition;
- operating conditions;
- age / condition of the electrolysis system;

- measurement method.

Therefore colleagues should say:

“Up to approximately 1500 ppb under suitable conditions.”

Not:

“Every cycle always gives exactly 1500 ppb.”

9. WHY HYDROGEN WATER SHOULD BE DRUNK FRESH

Molecular hydrogen is a gas.

After generation, dissolved H_2 gradually escapes from the water.

Therefore the best routine is:

GENERATE → DRINK FRESH

The longer the water is:

- left open;
- poured between containers;
- heated;
- stored;

the more hydrogen can be lost.

For everyday use, the simplest advice is:

Drink the water soon after the cycle finishes.

10. BOROSILICATE GLASS BODY

The GO bottle uses **borosilicate glass**.

This material was selected because it is:

- durable;
- transparent;
- lightweight relative to many conventional glass constructions;
- suitable for repeated everyday water use;
- resistant to ordinary temperature changes within the product's intended operating conditions.

The transparent body also allows the hydrogen-generation process to remain visible.

This creates one of GO's recognizable visual features:

water + visible bubbles + soft illumination.

11. COUNTDOWN TIMER

GO includes a:

built-in countdown timer

The timer allows the user to see the remaining generation time instead of guessing when the water is ready.

Customer Benefit - Clear, predictable preparation with minimal effort.

12. SOFT LED ILLUMINATION

The bottle includes soft LED illumination during operation.

This:

- makes the hydrogen-generation process visible;
- highlights the bubbles;
- gives the device a recognizable premium visual effect;

- makes it easy to see when a cycle is active.

The lighting should be positioned mainly as a **user-experience feature**, not as evidence of hydrogen concentration.

13. ANTI-SLIP BASE

GO includes an anti-slip base.

Its purpose is to improve stability on common surfaces and reduce unnecessary movement during operation.

This is especially useful on:

- desks;
 - kitchen counters;
 - bedside tables;
 - gym / office surfaces.
-

14. USB-C CHARGING

GO uses:

USB Type-C charging

This supports portable everyday use without a permanent power connection.

The rechargeable architecture makes the bottle practical for:

- work;
- gym;
- commuting;
- travel;
- home;
- office.

Exact battery capacity, charge time and number of cycles per charge should be taken from the final approved technical specification once confirmed.

15. WATER REQUIREMENTS

Use:

drinking-quality water only

The bottle is a Hydrogen Water generator.

It is **not** a water purification system.

Therefore it should not be used to make unsafe water safe.

Avoid filling it with:

- juice;
- tea;
- coffee;
- carbonated drinks;
- sweetened beverages;
- milk;
- other liquids not approved by the instructions.

Simple Rule

Start with water you would already be comfortable drinking.

16. WHAT GO IS DESIGNED FOR

GO is primarily designed for **simple everyday Hydrogen Water preparation**.

Ideal situations include:

- home
- office
- desk
- gym

- commute
- car
- train
- airplane travel
- outdoor activities
- daily hydration routine

Its main advantage is not having the largest number of functions.

Its advantage is:

SIMPLE + PORTABLE + FAST

17. GO VS PRO

This is one of the most important comparisons colleagues should know.

Feature	GO	PRO
Main positioning	Simple everyday Hydrogen Water	Premium hydrogen platform
H ₂	Up to ~1500 ppb	Up to ~9000 ppb
ORP	Down to ~-650 mV	Down to ~-750 mV
Capacity	400 mL	350 mL
Cycle	~5 min	3 / 18 min
Hydrogen inhalation	No dedicated function	Yes
Touchscreen	Simple interface / timer	Advanced touchscreen
App	No core smart positioning	Bluetooth app
Mineralization	No core alkaline option	Yes
Wireless charging	Not a core GO feature	Yes
Main advantage	Simplicity	Maximum functionality

Simplest Explanation

GO

Everyday Hydrogen Water

PRO

High-concentration Hydrogen Water + inhalation + smart functions

18. WHY CHOOSE GO INSTEAD OF PRO?

GO is not a “worse PRO.”

It is designed for a different user.

Choose GO when the customer values:

- simplicity;
- larger 400 mL drinking capacity;
- fast everyday routine;
- fewer settings;
- lighter mental load;
- easy portable use;
- lower complexity.

PRO is better suited to customers specifically looking for:

- higher hydrogen concentration;
- inhalation;
- advanced modes;
- app functions;
- mineralization;
- premium smart features.

The strongest sales approach is not to make GO and PRO compete.

They serve **different use cases**.

19. WHY GO HAS A LARGER BOTTLE THAN PRO

GO capacity:

400 mL

PRO capacity:

350 mL

GO is designed primarily as an everyday drinking bottle.

Therefore a slightly larger water volume makes sense for its main use case.

PRO uses more internal space for additional technology and functions such as:

- higher-concentration generation;
 - inhalation architecture;
 - advanced electronics;
 - touchscreen;
 - additional systems.
-

20. GO VS WATER IONIZER HYDROGEN MODE

The Water Ionizer also has a Hydrogen Water program, but the products serve different purposes.

GO

- personal portable bottle;
- up to approximately 1500 ppb;
- approximately 5-minute preparation;
- 400 mL;
- designed to travel with the user.

Water Ionizer

- countertop multi-water system;
- Hydrogen Water is one of four functions;
- up to approximately 300 ppb H₂;
- prepares approximately 3.5 L;
- also produces Alkaline, Acidic and Silver Ion.

Simple Difference

Water Ionizer = large-volume multifunction water system

GO = portable personal Hydrogen Water bottle

21. WHAT THE PRODUCT IS NOT

GO is not:

- a water purifier;
- a reverse-osmosis system;
- an alkaline-water ionizer;
- a medical device;
- a hydrogen inhalation device;
- an oxygen generator;
- a treatment for disease;
- a substitute for medication;
- a system that makes unsafe water safe.

Its purpose is simple:

to enrich suitable drinking water with dissolved molecular hydrogen.

22. CLEANING & EVERYDAY CARE

For everyday use:

- use clean drinking water;
- rinse the water-contact area regularly;
- do not allow residue to build up;
- keep the charging port dry;

- do not immerse the electronic base in water;
- dry the device properly when storing it.

If the unit has been unused for an extended period, follow the approved reactivation / rinsing procedure from the final instruction before normal use.

Do not use aggressive abrasive cleaners on the bottle or electronic base.

23. WHY VISIBLE BUBBLES ARE NOT THE MAIN MEASUREMENT

Customers may assume:

more bubbles = more hydrogen

This is not necessarily accurate.

Visible gas bubbles show that gas generation is occurring, but the important parameter for Hydrogen Water is:

how much molecular H_2 remains dissolved in the water.

That is why hydrogen concentration is expressed in:

ppb / ppm

instead of simply counting bubbles.

24. WHY ppb CAN VARY

Hydrogen concentration is affected by multiple factors.

These can include:

- water composition;
- water temperature;
- cycle conditions;
- electrolysis system performance;

- hydrogen loss after generation;
- measurement method.

Therefore:

“up to 1500 ppb”

is more accurate than promising an identical result with every type of water and every cycle.

25. FEATURE → CUSTOMER BENEFIT

Approximately 5-Minute Cycle

Benefit: easy to integrate into a normal daily routine.

Up to ~1500 ppb H₂

Benefit: concentrated molecular Hydrogen Water in a compact personal bottle.

400 mL Capacity

Benefit: practical everyday drinking volume.

Borosilicate Glass

Benefit: durable transparent water chamber with visible hydrogen generation.

Countdown Timer

Benefit: the user always knows when the cycle will finish.

Soft LED Illumination

Benefit: clear visual indication and more enjoyable user experience.

One-Button Operation

Benefit: almost no learning curve.

Anti-Slip Base

Benefit: greater stability during everyday use.

USB-C Charging

Benefit: convenient charging at home, office or while travelling.

26. KEY SELLING POINTS

Every colleague should remember:

1. **Portable everyday Hydrogen Water bottle**
 2. **Up to approximately 1500 ppb H₂**
 3. **ORP down to approximately -650 mV**
 4. **Approximately 5-minute cycle**
 5. **400 mL capacity**
 6. **Simple one-button operation**
 7. **Built-in countdown timer**
 8. **Visible hydrogen bubbles**
 9. **Soft LED illumination**
 10. **Borosilicate-glass bottle**
 11. **USB-C rechargeable**
 12. **Anti-slip base**
 13. **Designed for home, office, gym and travel**
 14. **Simpler alternative to PRO**
-

27. QUICK FAQ

What does GO do?

It enriches drinking water with dissolved molecular hydrogen H₂.

How much hydrogen can it produce?

Up to approximately:

1500 ppb H₂

under suitable conditions.

What is the ORP?

Up to approximately:

-650 mV

depending on water and operating conditions.

How long does preparation take?

Approximately:

5 minutes

How much water does it hold?

400 mL

Is it alkaline water?

Not necessarily.

Hydrogen concentration and pH are different parameters.

Does it filter the water?

No.

Use drinking-quality water.

Do I need special water?

Use suitable drinking water according to the product instructions.

Can I put juice or coffee inside?

No. Use the device for approved drinking water only.

Does it have a timer?

Yes, it has a built-in countdown timer. [ТЗ Ф3/Племя](#)

Why does it light up?

Soft LED illumination makes the operating process and hydrogen bubbles visible.

Does it charge with USB-C?

Yes.

Can I take it to the gym or office?

Yes. Portability is one of its main use cases.

Does it do hydrogen inhalation?

GO is designed primarily for Hydrogen Water. Dedicated hydrogen inhalation is a PRO feature.

Why choose GO instead of PRO?

Choose GO for simpler everyday Hydrogen Water preparation. Choose PRO for high concentration, inhalation and advanced smart functions.

28. COMMON OBJECTIONS

“Why do I need a special bottle just for water?”

GO doesn't simply store water. It generates dissolved molecular hydrogen directly before drinking, so the water can be prepared fresh when you need it.

“Why not buy Hydrogen Water in a bottle?”

Hydrogen gradually escapes during storage. A portable generator allows the user to prepare Hydrogen Water immediately before drinking instead of relying on a product that may have been stored for a long time.

“PRO has much more hydrogen. Why would I buy GO?”

They are designed for different users. GO focuses on simplicity, a larger 400 mL drinking volume and an easy everyday routine. PRO focuses on maximum concentration, inhalation and advanced functions.

“Does more negative ORP mean more hydrogen?”

Not exactly. ORP and dissolved H₂ concentration are related to different measurements. Hydrogen itself should be measured in ppb or ppm.

“Can I use it as my normal water bottle all day?”

It is designed as a portable drinking bottle, but Hydrogen Water is best consumed relatively soon after generation because dissolved H₂ gradually escapes.

29. CLAIMS TO USE CAREFULLY

Do not independently claim that GO:

- cures disease;
- prevents cancer;
- treats hypertension;
- detoxes the body;
- replaces medication;
- is a medical device;
- provides medical hydrogen therapy;
- changes the body's pH;
- guarantees exactly 1500 ppb every cycle;
- guarantees exactly -650 mV with every water source;
- purifies unsafe water;
- sterilizes water;
- removes all contaminants;
- has proven anti-aging effects;
- provides guaranteed athletic recovery.

Keep the explanation focused on:

technology + dissolved H₂ concentration + portability + convenience.

30. DO NOT CONFUSE

Hydrogen Water ≠ Alkaline Water

H₂ concentration ≠ pH

H₂ concentration ≠ ORP

Visible bubbles ≠ measured ppb

Hydrogen generation ≠ water purification

GO ≠ hydrogen inhalation system

GO ≠ PRO

Portable bottle ≠ Water Ionizer

31. CORE NUMBERS TO MEMORIZE

Every colleague should know:

Up to ~1500 ppb H₂

Hydrogen concentration

Down to ~-650 mV

ORP

~5 minutes

Hydrogen-generation cycle

400 mL

Capacity

1.5 ppm

Equivalent of 1500 ppb H₂

USB Type-C

Charging

32. FIVE THINGS EVERY COLLEAGUE MUST REMEMBER

1.

GO is the simple everyday Hydrogen Water bottle.

2.

It produces up to approximately 1500 ppb H₂ in an approximately 5-minute cycle.

3.

It has a 400 mL borosilicate-glass bottle with one-button operation, countdown timer and soft LED illumination.

4.

GO is different from PRO: GO focuses on simplicity; PRO focuses on high concentration, inhalation and smart functions.

5.

Never confuse Hydrogen Water with alkaline water or turn Hydrogen Water features into medical claims.

33. FINAL POSITIONING

A simple portable Hydrogen Water bottle designed to make fresh molecular Hydrogen Water part of an everyday routine — at home, at work, at the gym or on the go.

The strongest product story is:

****Up to ~1500 ppb H₂**

- ORP down to ~-650 mV
- ~5-minute preparation
- 400 mL capacity
- One-button operation
- Countdown timer
- Soft LED illumination
- Borosilicate glass
- USB-C charging
- Anti-slip base
- Everyday portability**

The simplest distinction for colleagues to remember is:

GO = easy everyday Hydrogen Water.

PRO = advanced high-concentration hydrogen platform.

AIR HUMIDIFIER

AIR HUMIDIFIER

Product Training Guide

1. PRODUCT AT A GLANCE

The Air Humidifier is a compact **ultrasonic humidifier** designed to add moisture to indoor air by converting water into a fine mist.

It combines three functions:

Humidification

Produces up to **300 mL of mist per hour**.

Aromatherapy

Compatible with **100% natural essential oils**.

Ambient Lighting

Integrated lighting with several illumination modes, including a candle-effect night mode.

2. KEY TECHNICAL SPECIFICATIONS

Parameter	Specification
Type	Ultrasonic
Maximum mist output	300 mL/h
Water tank	2.4 L
Recommended coverage	up to 36–38 m² / 90 m³
Humidification modes	4

Timer	2 / 4 / 6 hours
Auto shut-off	Yes, when water runs out
Rated voltage	220 V
Power	25 W
Noise level	up to 38 dB
Dimensions	170 × 170 × 300 mm
Weight	990 g
Power cord	1.5 m
Materials	ABS + PP
Atomization technology	Piezoelectric / ultrasonic
Atomizer expected lifespan	>5,000 operating hours

3. ONE-LINE EXPLANATION

A compact 3-in-1 ultrasonic humidifier with four mist modes, aromatherapy support and atmospheric lighting, designed for rooms up to 40 m²/ 90 m³.

4. 30-SECOND EXPLANATION

This is a 3-in-1 ultrasonic Air Humidifier designed for everyday indoor comfort. It combines humidification, aromatherapy and atmospheric lighting in one compact device. A 2.4-liter tank and four mist modes provide output from 35 to 300 mL per hour, with coverage up to 90 m³. It also features a 2/4/6-hour timer, automatic shut-off when the water runs out, and operates at up to 38 dB.

5. HOW IT WORKS

The humidifier uses **ultrasonic atomization**.

Step 1 — Water is added

The user fills the **2.4 L reservoir**.

Step 2 — The piezoelectric atomizer activates

A piezoelectric ceramic element uses high-frequency vibration to break water into extremely fine droplets.

Step 3 — Fine mist is released

The device releases fine water mist through the top outlet.

Step 4 — Moisture disperses through the room

The mist mixes with the surrounding air and increases indoor humidity.

Simple Explanation

Water → Ultrasonic vibration → Fine mist → Humidified indoor air

6. ULTRASONIC TECHNOLOGY

The Air Humidifier is an:

Ultrasonic Humidifier

Unlike steam humidifiers, it does not need to boil the water to create mist.

Its piezoelectric ceramic atomizer converts water into fine droplets through ultrasonic vibration.

Customer Benefits

- fine mist generation;
- compact system;
- relatively low power consumption;

- up to 300 mL/h mist output;
 - suitable for bedroom, living room, nursery and office environments.
-

7. FOUR HUMIDIFICATION MODES

One of the key advantages of the product is that the user can choose the mist intensity depending on the situation.

LOW MODE — 100 mL/h

Designed for:

- nighttime use;
 - smaller rooms;
 - gentle continuous humidification.
-

MEDIUM MODE — 200 mL/h

Designed for:

- regular daytime use;
 - everyday humidity support.
-

HIGH MODE — 300 mL/h

Maximum humidification output.

Designed for:

- faster humidification;
 - use after ventilation;
 - periods when heating or air conditioning has made the air particularly dry.
-

NIGHT MODE — 35 mL/h

Very low mist output designed for nighttime use.

It combines:

- reduced evaporation;
 - low-intensity operation;
 - special **Candle lighting mode**.
-

8. MIST OUTPUT

The maximum output is:

300 mL/h

The exact output depends on the selected mode:

Night: 35 mL/h

Low: 100 mL/h

Medium: 200 mL/h

High: 300 mL/h

This allows the user to adjust humidification rather than operating at maximum output continuously.

9. WATER TANK

Tank capacity: **2.4 L**

The relatively large tank allows the device to operate for extended periods without constant refilling.

Actual runtime depends on the selected mist mode.

Do not promise an exact runtime unless it is calculated and officially confirmed for each operating mode.

10. ROOM COVERAGE

Recommended maximum room coverage:

36–38 m² or approximately: 90 m³

Typical use environments include:

- bedroom;
- nursery;
- living room;
- home office;
- office.

Important

Coverage depends on:

- room dimensions;
 - ventilation;
 - starting humidity;
 - temperature;
 - selected output mode;
 - whether doors and windows remain open.
-

11. TIMER

The humidifier includes three timer settings:

2 hours 4 hours 6 hours

This is useful for:

- nighttime operation;
- office use;
- scheduled humidification;
- avoiding unnecessary continuous operation.

12. AUTOMATIC SHUT-OFF

The device has:

Automatic shut-off when the water runs out

This means the humidifier is designed to stop operating when there is insufficient water in the reservoir.

This is an important safety and convenience feature.

13. NOISE LEVEL

Maximum stated noise level:

up to 38 dB

For training purposes, use:

“Operates at up to 38 dB.”

Avoid describing it as **completely silent**.

The marketing materials use “practically silent,” but **38 dB** is the more precise specification.

14. POWER CONSUMPTION

Rated power: **25 W**

Voltage: **220 V**

This gives the device relatively low power consumption compared with many heating-based appliances.

For international white-label projects, the voltage specification must be adapted or confirmed for each target market.

15. AROMATHERAPY FUNCTION

The product can also function as an:

Aroma Diffuser

The current product materials explicitly allow:

100% natural essential oils

This makes the unit a:

Humidifier + Aroma Diffuser

Recommended Filling Sequence

According to the current product instructions:

1. Fill approximately **1/3 of the reservoir with water**.
2. Add the essential oil.
3. Fill the remaining reservoir with water.

Important

Only use essential oils permitted by the operating instructions.

The current infographic specifically refers to:

100% natural essential oils.

16. HUMIDIFIER + AROMA DIFFUSER + LIGHT

The product can be positioned as:

3-in-1

1. Humidifies

Adds moisture to indoor air.

2. Aromatizes

Supports compatible natural essential oils.

3. Illuminates

Integrated atmospheric lighting can also function as a night light.

This is a much stronger positioning than presenting it only as a basic humidifier.

17. ATMOSPHERIC LIGHTING

The humidifier includes integrated atmospheric lighting.

There are three main lighting experiences.

CONSTANT LIGHT

Soft continuous illumination.

Suitable for:

- ambient lighting;
 - bedside use;
 - relaxed evening environments.
-

FLICKERING LIGHT

Smooth brightness variation.

Brightness settings:

- low;
 - medium;
 - high.
-

CANDLE MODE

Imitates the visual effect of a small flame.

Available in:

Night Mode

This creates a more atmospheric bedside experience.

18. NIGHT-LIGHT FUNCTION

The integrated lighting allows the humidifier to also function as a:

Night Light

The product materials position it for:

- evening relaxation;
- bedroom atmosphere;
- meditation;
- nighttime use.

This feature adds a lifestyle component that differentiates the product from very basic humidifiers.

19. HUMIDITY RANGE

The product materials present:

40–60% relative humidity

as an optimal indoor comfort range.

For sales training, say:

“The humidifier is designed to help create a comfortable indoor humidity environment, with 40–60% used as the target range in our product materials.”

20. INDOOR COMFORT BENEFITS

Dry indoor air can contribute to discomfort affecting:

- skin;
- nose and throat;
- general breathing comfort;
- sleep environment.

A humidifier adds moisture to the air and may help reduce discomfort associated with an overly dry indoor environment.

The consumer materials associate the product with:

- comfortable sleep;
- pleasant breathing;
- everyday comfort;
- a more comfortable indoor environment.

“Helps reduce discomfort associated with dry indoor air.”

21. DIMENSIONS AND WEIGHT

Dimensions

170 × 170 × 300 mm

Weight

990 g

This makes it relatively easy to:

- move between rooms;
 - place on a bedside table;
 - use in an office;
 - relocate when required.
-

22. MATERIALS

Housing materials:

ABS + PP

These are the materials stated in the technical specifications.

Do not add claims such as:

- BPA-free;
- food-grade;
- antibacterial plastic;

unless separately documented.

23. FILTER SYSTEM

The package contains:

3 air filters

Configuration:

- **1 installed**
- **2 additional filters included**

24. WHAT IS INCLUDED

The current package includes:

- **Air Humidifier**
 - **2.4 L water reservoir**
 - **3 air filters**
 - 1 installed
 - 2 spare
 - **1.5 m power cable**
 - **Instruction manual**
 - **Retail packaging**
-

25. ATOMIZER LIFESPAN

The expected service life of the piezoelectric ceramic atomizer is:

more than 5,000 operating hours

This refers to actual operating time.

Do not convert this into a guaranteed number of years because service life depends on:

- frequency of use;
- water quality;
- mineral buildup;
- cleaning;
- maintenance;
- operating conditions.

Correct wording:

“The ultrasonic atomizer is designed for more than 5,000 operating hours.”

26. USE WITH ESSENTIAL OILS

This point can now be removed from the “unconfirmed” section.

YES — Essential oils are supported.

Current instructions specify:

Use only 100% natural essential oils.

Filling Order

Water first → essential oil → remaining water

Do not add concentrated oil directly to an empty reservoir unless specifically instructed.

27. SILVER ION COMPATIBILITY

If we keep the previously discussed ecosystem integration with the Water Ionizer, the compatible Air Humidifier can also be positioned for use with approved **Silver Ion water**.

However:

the exact approved Ag^+ concentration still needs confirmation.

Do not independently choose a Silver Ion concentration.

Also do not claim that using Silver Ion in the humidifier automatically:

- sterilizes the room;
- kills airborne viruses;
- disinfects surfaces;
- prevents infections.

Those claims would require separate testing of the complete system.

28. AIR HUMIDIFIER VS AIR PURIFIER

These products serve completely different functions.

AIR HUMIDIFIER

Changes:

Moisture / humidity

Main purpose:

Adds moisture to indoor air.

AIR PURIFIER

Changes:

Air contaminant load

Main purpose:

Treats certain contaminants passing through the purification system.

Simplest Explanation

Air Purifier = cleaner air

Air Humidifier = more comfortable humidity

They complement one another but are not interchangeable.

29. AIR HUMIDIFIER VS AROMA DIFFUSER

Unlike a dedicated aroma diffuser, this product's main function is:

humidification

Aromatherapy is an additional feature.

Therefore:

Humidification = primary function

Aromatherapy = additional function

Atmospheric lighting = additional function

30. IDEAL USE ENVIRONMENTS

Bedroom

Low and Night Modes are particularly suitable.

Nursery

Compact indoor humidification.

Living Room

Medium or High Mode depending on conditions.

Office

For dry indoor environments caused by heating or air conditioning.

Coverage:

up to 36–38 m² / 90 m³

31. KEY SELLING POINTS

Every colleague should remember these:

1. **3-in-1: Humidifier + Aroma Diffuser + Ambient Light**
 2. **Ultrasonic humidification**
 3. **2.4 L water tank**
 4. **Up to 300 mL/h mist output**
 5. **Four humidification modes**
 6. **35 / 100 / 200 / 300 mL/h output options**
 7. **Up to 36–38 m² / 90 m³ room coverage**
 8. **2 / 4 / 6-hour timer**
 9. **Automatic shut-off when water runs out**
 10. **Up to 38 dB noise level**
 11. **25 W power**
 12. **Atmospheric lighting + Candle Mode**
 13. **Compatible with 100% natural essential oils**
 14. **Compact: 17 × 17 × 30 cm**
 15. **Lightweight: 990 g**
 16. **3 filters included**
 17. **Piezoelectric atomizer designed for >5,000 hours**
-

32. FEATURE → CUSTOMER BENEFIT

2.4 L Tank

Benefit: less frequent refilling.

Four Mist Modes

Benefit: user can adapt output for daytime, nighttime or faster humidification.

Up to 300 mL/h

Benefit: stronger output when quicker humidification is required.

Night Mode — 35 mL/h

Benefit: reduced output for nighttime use.

38 dB Maximum Noise Level

Benefit: designed for relatively quiet indoor use.

Timer

Benefit: automatically limits operating time to 2, 4 or 6 hours.

Water-Level Auto Shut-Off

Benefit: stops the device when the reservoir is empty.

Essential Oil Compatibility

Benefit: combines humidification with aromatherapy.

Candle Lighting

Benefit: creates a softer evening atmosphere and can function as a night light.

25 W Power

Benefit: relatively low-power operation.

<1 kg Weight

Benefit: easy to move around the home.

33. QUICK FAQ

What type of humidifier is it?

An ultrasonic humidifier.

How large is the water tank?

2.4 liters.

What is the maximum output?

300 mL/h.

How many humidification modes are there?

Four.

What are the output levels?

35, 100, 200 and 300 mL/h.

What room size is it designed for?

Up to approximately **36–38 m² / 90 m³.**

How loud is it?

Rated at up to **38 dB.**

Does it turn off automatically?

Yes. It includes **automatic shut-off when the water runs out.**

Does it have a timer?

Yes:

2 / 4 / 6 hours.

Can I use essential oils?

Yes. Current instructions specify **100% natural essential oils.**

Does it have lighting?

Yes.

It includes multiple lighting options and a special **Candle Mode** for nighttime use.

Can it be used as a night light?

Yes.

How much power does it use?

25 W.

How much does it weigh?

990 g.

What are the dimensions?

170 × 170 × 300 mm.

How many filters are included?

Three: one installed and two spare filters.

Does it automatically maintain 40–60% humidity?

The marketing material presents 40–60% as the target humidity range, but automatic humidity sensing has **not yet been confirmed**.

34. COMMON OBJECTIONS

“Why do I need several modes?”

Different environments require different mist output. You can choose 35 mL/h for Night Mode, 100 mL/h for gentle humidification, 200 mL/h for regular daytime use or 300 mL/h when faster humidification is needed.

“Can I use it while sleeping?”

Yes. The device includes a dedicated Night Mode with 35 mL/h output and a Candle lighting effect. It operates at up to 38 dB.

“Can I add essential oils?”

Yes. The product supports 100% natural essential oils. Follow the filling instructions and use only approved oils.

“What happens when the water runs out?”

The device is designed to shut off automatically when there is no water.

“Is it an air purifier?”

No. Its primary function is humidification. An Air Purifier addresses air contaminants; this product adds moisture.

35. CLAIMS TO USE CAREFULLY

Do not independently claim that the humidifier:

- treats asthma;
- treats allergies;
- prevents infections;
- cures respiratory conditions;
- boosts immunity;
- guarantees better sleep;
- sterilizes a room;
- kills viruses;
- removes pollutants from the air;
- automatically maintains exactly 40–60% humidity unless a sensor is confirmed;
- is completely silent;
- is a medical nebulizer.

Prefer:

“Helps create a more comfortable indoor environment by adding moisture to dry air.”

36. CORE NUMBERS TO MEMORIZE

2.4 L

Water tank

300 mL/h

Maximum mist output

35 / 100 / 200 / 300 mL/h

Four operating modes

36–38 m² / 90 m³

Maximum recommended room coverage

2 / 4 / 6 hours

Timer

38 dB

Maximum stated noise

25 W

Power

220 V

Rated voltage

17 × 17 × 30 cm

Dimensions

990 g

Weight

1.5 m

Cable length

>5,000 hours

Expected atomizer life

3 filters

1 installed + 2 spare

37. FIVE THINGS EVERY COLLEAGUE MUST REMEMBER

1.

It is a 3-in-1 product: humidifier, aroma diffuser and ambient light.

2.

It has a 2.4 L tank and four mist modes from 35 to 300 mL/h.

3.

It is designed for rooms up to approximately 36–38 m² / 90 m³.

4.

It includes a timer, automatic shut-off and nighttime Candle lighting.

5.

The main function is indoor humidification — do not turn normal comfort benefits into medical claims.

HYDROGEN FOR FACE & BODY

HYDROGEN GENERATOR FOR FACE & BODY

1. PRODUCT AT A GLANCE

The Hydrogen Generator for Face & Body is a **portable skincare device that converts water into an ultrafine mist and enriches it with molecular hydrogen H₂.**

It is designed for quick topical hydration of the skin at home or on the go.

Key Facts

- **Hydrogen concentration:** up to 500 ppb H₂
 - **ORP:** down to approximately -300 mV
 - **Mist cycle:** approximately 55 seconds
 - **Reservoir:** 15 mL
 - **Ultrasonic frequency:** 160 kHz
 - **Battery:** 1500 mAh
 - **Charging:** USB Type-C
 - **Charging time:** approximately 1–2 hours
 - **Power:** ≤5 W
 - **Dimensions:** 15.8 × 3.7 × 3 cm
 - **Body:** ABS plastic
 - **Water reservoir:** food-grade thermoplastic polyethylene
 - **Water:** low- or medium-mineralization drinking water
 - **Maximum water temperature:** 45°C / 113°F
-

2. ONE-LINE EXPLANATION

A portable face-and-body skincare device that transforms water into an ultrafine hydrogen-enriched mist for quick everyday skin hydration.

3. 30-SECOND EXPLANATION

This portable Hydrogen Generator is designed to bring the benefits of molecular hydrogen directly to the skin. Hydrogen-enriched water is used in skincare for its antioxidant properties and its potential to help reduce oxidative stress while supporting skin hydration and a fresher-looking appearance. The device transforms water into an ultrafine hydrogen-rich mist with up to 500 ppb H_2 , allowing it to be applied easily to the face and body. One cycle takes approximately 55 seconds, making it a simple addition to everyday skincare at home or on the go.

Why hydrogen → what it may do for the skin → how the device delivers it → why it is convenient.

4. HOW IT WORKS

The device combines two processes:

Ultrasonic Atomization

Water is broken into very fine droplets using high-frequency vibration.

Hydrogen Enrichment

The water is enriched with molecular hydrogen: H_2

The resulting fine mist is released directly onto the skin.

Simple Explanation

Water → Ultrasonic atomization → Hydrogen-enriched fine mist → Skin

5. ULTRASONIC TECHNOLOGY

The device operates at approximately:

160 kHz

This high-frequency vibration converts water into a fine mist without producing hot steam.

Important

This is **not a facial steamer**.

It creates: **cool ultrafine mist**, not hot vapor.

6. HYDROGEN PARAMETERS

Hydrogen Concentration

Up to: **500 ppb H₂**

ORP Down to approximately: **-300 mV**

These are different parameters.

Hydrogen concentration ≠ ORP

Hydrogen is measured in ppb.

ORP is measured in mV and describes oxidation-reduction conditions.

7. ONE-CYCLE ROUTINE

One mist cycle lasts approximately: **55 seconds**

How to Use

1. Open the upper lid.
2. Fill with suitable drinking water.
3. Close the lid securely.
4. Slide the switch downward.

5. The mist starts and the indicator turns blue.
 6. Apply the mist to the face or body.
 7. The cycle lasts approximately 55 seconds.
 8. Slide the switch upward to stop manually.
-

8. FACE & BODY USE

The device can be used for quick topical misting of:

- face;
- neck;
- décolleté;
- hands;
- arms;
- other body areas.

It is designed as a **portable skincare and hydration device**, not only as a facial product.

Typical Use Situations

- morning skincare;
 - during the day;
 - after cleansing;
 - office;
 - travel;
 - airplane;
 - hotel;
 - dry indoor environments.
-

9. WATER REQUIREMENTS

Use only: **Low- or medium-mineralization drinking water**

Do not use:

- highly mineralized water;
- lotions;
- toners;

- serums;
- cosmetic products;
- essential oils;
- perfumes;
- other liquids.

These substances may damage the device or block the misting system.

11. FIRST USE

Before first use:

1. Fill the reservoir with warm drinking water at **35–45°C / 95–113°F**.
 2. Leave it for approximately **30 minutes** with the device turned off.
 3. Pour out the water.
 4. Rinse the reservoir several times.
 5. Fully charge the device.
 6. Refill with fresh drinking water.
-

12. CHARGING

Charging Port

USB Type-C

Battery

1500 mAh

Full Charging Time

Approximately:

1–2 hours

Recommended Adapter

5 V / 2 A

Indicator:

Red = charging

Green = fully charged

Do not use fast-charging adapters.

13. RESERVOIR

Water reservoir:

15 mL

Because the device is designed for direct skincare misting rather than room humidification, it does not require a large water tank.

The small reservoir supports its compact, portable format.

14. PORTABILITY

Dimensions:

15.8 × 3.7 × 3 cm

The slim handheld design makes the device easy to:

- carry in a handbag;
 - keep at a desk;
 - use while travelling;
 - include in a daily skincare routine.
-

15. TILT LIMIT

During operation:

Do not tilt more than 45°.

Excessive tilting may cause:

- water leakage;
- misting problems;
- damage to the spray nozzle.

If transporting the device with water inside: **keep it vertical.**

16. CLEANING & MAINTENANCE

Rinse the water reservoir and lid with clean water.

At least: **once per month** perform deeper cleaning.

Cleaning Solution

3 g citric acid / 30 mL warm drinking water at 35–45°C

Procedure

1. Dissolve the citric acid.
2. Pour it into the reservoir.
3. Leave for **30 minutes** with the device turned off.
4. Empty the reservoir.
5. Rinse thoroughly several times with clean water.

Do not wash the device in a dishwasher

17. SAFETY

Do not:

- operate with an empty reservoir;

- use water above 45°C;
- immerse the device in water;
- block the mist nozzle;
- tilt more than 45° during use;
- use highly mineralized water;
- add cosmetics or lotions;
- use unsupported fast charging;
- expose the device to extreme temperatures.

If skin irritation or another negative reaction occurs: **stop using the device.**

18. PACKAGE CONTENTS

The package includes:

- **Hydrogen Generator for Face & Body**
 - **USB cable**
 - **User manual**
-

19. WHAT IT IS NOT

The device is not:

- a room humidifier;
- a Hydrogen Water Bottle;
- a hot facial steamer;
- a medical nebulizer;
- a hydrogen inhalation device;
- a medical device;
- a water purifier;
- a serum or cosmetic atomizer.

Its main purpose is:

Hydrogen-enriched fine mist for topical skincare.

22. KEY SELLING POINTS

1. Hydrogen-enriched fine mist
 2. Face & body use
 3. Up to 500 ppb H₂
 4. ORP down to approximately -300 mV
 5. 160 kHz ultrasonic mist technology
 6. ~55-second skincare cycle
 7. Compact 15 mL reservoir
 8. Portable handheld design
 9. 1500 mAh rechargeable battery
 10. USB-C charging
 11. 1–2 hour charging time
 12. Simple one-switch operation
-

23. FEATURE → CUSTOMER BENEFIT

160 kHz Ultrasonic Mist

Benefit: creates a very fine mist for lightweight skin application.

Molecular Hydrogen

Benefit: adds hydrogen-skincare functionality to the mist.

~55-Second Cycle

Benefit: quick enough for everyday and on-the-go routines.

15 mL Reservoir

Benefit: keeps the device small and portable.

1500 mAh Battery

Benefit: cordless use away from a power outlet.

USB-C

Benefit: convenient charging at home or while travelling.

24. QUICK FAQ

What does it do?

Creates a fine hydrogen-enriched mist for topical skincare.

How much hydrogen?

Up to **500 ppb H₂**.

What is the ORP?

Approximately **-300 mV**.

How long is one cycle?

Approximately **55 seconds**.

How much water does it hold?

15 mL.

What technology does it use?

160 kHz ultrasonic atomization.

Can I use it on the body?

Yes. It is designed for topical skin use, including face and body.

Can I add serum?

No.

Can I add Silver Ion?

No.

Can I use essential oils?

No.

What water should I use?

Low- or medium-mineralization drinking water.

How long does charging take?

Approximately **1–2 hours**.

Is it a facial steamer?

No. It produces fine mist, not hot steam.

25. CLAIMS TO USE CAREFULLY

The source manual discusses antioxidant activity, free radicals, inflammation, skin hydration, skin texture and UV-related effects. Itdbuf4qxhq2rqueso9o5p3ne6x0pjxn...

Until we have supporting evidence ready, do not independently claim that the device:

- reverses aging;
- removes wrinkles;
- cures acne;
- treats dermatitis or eczema;
- eliminates inflammation;
- protects the skin instead of sunscreen;
- repairs UV damage;
- provides medical treatment.

Preferred wording

Hydrogen-enriched skincare mist

Designed for face & body hydration

Portable molecular-hydrogen beauty routine

Ultrafine mist for everyday skincare

26. CORE NUMBERS TO MEMORIZE

500 ppb H₂

Hydrogen concentration

-300 mV

ORP

160 kHz

Ultrasonic frequency

55 sec

One mist cycle

15 mL

Reservoir

1500 mAh

Battery

1-2 h

Charging time

≤5 W

Power

15.8 × 3.7 × 3 cm

Dimensions

45°C / 113°F

Maximum water temperature

45°

Maximum operating tilt

12 months

Reference warranty

27. FIVE THINGS EVERY COLLEAGUE MUST REMEMBER

1.

It is a portable Hydrogen Generator for Face & Body, not a room humidifier.

2.

It creates hydrogen-enriched ultrafine mist with up to 500 ppb H₂.

3.

One skincare cycle takes approximately 55 seconds.

4.

Use only low- or medium-mineralization drinking water — no cosmetics, Silver Ion or essential oils.

5.

Position it as a portable skincare and hydration device, not as a medical or guaranteed anti-aging treatment.